

ASAE S471 MAR1991 (R2018)
Procedure for Measuring Sprayer Nozzle Wear Rate



**American Society of
Agricultural and Biological Engineers**

**S
T
A
N
D
A
R
D**

ASABE is a professional and technical organization, of members worldwide, who are dedicated to advancement of engineering applicable to agricultural, food, and biological systems. ASABE Standards are consensus documents developed and adopted by the American Society of Agricultural and Biological Engineers to meet standardization needs within the scope of the Society; principally agricultural field equipment, farmstead equipment, structures, soil and water resource management, turf and landscape equipment, forest engineering, food and process engineering, electric power applications, plant and animal environment, and waste management.

NOTE: ASABE Standards, Engineering Practices, and Data are informational and advisory only. Their use by anyone engaged in industry or trade is entirely voluntary. The ASABE assumes no responsibility for results attributable to the application of ASABE Standards, Engineering Practices, and Data. Conformity does not ensure compliance with applicable ordinances, laws and regulations. Prospective users are responsible for protecting themselves against liability for infringement of patents.

ASABE Standards, Engineering Practices, and Data initially approved prior to the society name change in July of 2005 are designated as "ASAE", regardless of the revision approval date. Newly developed Standards, Engineering Practices and Data approved after July of 2005 are designated as "ASABE".

Standards designated as "ANSI" are American National Standards as are all ISO adoptions published by ASABE. Adoption as an American National Standard requires verification by ANSI that the requirements for due process, consensus, and other criteria for approval have been met by ASABE.

Consensus is established when, in the judgment of the ANSI Board of Standards Review, substantial agreement has been reached by directly and materially affected interests. Substantial agreement means much more than a simple majority, but not necessarily unanimity. Consensus requires that all views and objections be considered, and that a concerted effort be made toward their resolution.

CAUTION NOTICE: ASABE and ANSI standards may be revised or withdrawn at any time. Additionally, procedures of ASABE require that action be taken periodically to reaffirm, revise, or withdraw each standard.

Copyright American Society of Agricultural and Biological Engineers. All rights reserved.

ASABE, 2950 Niles Road, St. Joseph, MI 49085-9659, USA, phone 269-429-0300, fax 269-429-3852, hq@asabe.org

ASAE S471 MAR1991 (R2018)

Procedure for Measuring Sprayer Nozzle Wear Rate

Developed by the ASAE Agricultural Chemical Application Committee; approved by the Power and Machinery Division Standards Committee; adopted by ASAE March 1991; reaffirmed December 1995, January 2001, December 2001, February 2003, February 2008, December 2012, October 2018.

Keywords: Nozzle, Sprayer, Test procedure

1 Purpose and scope

1.1 This Standard establishes a test procedure for measuring and reporting the wear rates of agricultural sprayer nozzles used with abrasive materials.

1.2 This Standard pertains to agricultural nozzles that use hydraulic energy to atomize the liquid. The Standard is primarily for nozzles with flow rates up to 3 L/min.

2 Essential elements of a test

2.1 It is essential to specify certain equipment and procedures for nozzle wear tests in order to satisfactorily compare the results of various tests. A standard reference nozzle is necessary in order to compare various nozzle wear test systems and different nozzles used in the systems.

2.1.1 Standard reference nozzle. Three, SAE 303 series stainless steel, flat-fan-pattern nozzles with an 80 ± 5 deg spray angle when measured at 275 kPa shall be included in each test. So that all nozzles produce about the same amount of wear on the abrasive particles, the mean flow rate of the reference nozzles should be within $\pm 25\%$ of the mean flow rate of each other type of nozzle at all times during the test. When the mean flow rate difference between the reference nozzles and any other type of nozzle approaches 25%, the nozzles (reference or test) with greater flow rate should be replaced. The test can then be continued to determine the effect of time on flow rates delivered by the other nozzles.

2.2 At least three nozzles of each type shall be included in all tests. All nozzles should have initial flow rates within $\pm 5\%$ of the mean flow rate of all nozzles of the same type. Each nozzle should be randomly selected from all nozzles for position on the test stand. Each nozzle should contain the strainer as recommended by the nozzle manufacturer. When testing fan-pattern and flooding-type nozzles, at least one test should be made with 275 kPa pressure at the nozzle. For cone-pattern nozzles, at least one test should be with either 275 or 500 kPa pressure. Select the pressure closer to the pressure at which the nozzle is generally used. All tests should be long enough to achieve at least 10% increase in the mean flow rate of the nozzle being tested or of the standard reference nozzle.

2.3 Tank. The tank size will be determined by the flow rate and number of nozzles to be used during a test. The spray from all nozzles should be protected from wind and returned to the tank. The temperature of the liquid in the tank should never exceed 50°C during the test.

2.3.1 Agitation. The tank shall have a shape and agitation system such that a uniform mixture of water and abrasive is ensured throughout the tank for the duration of test. Excessive agitation which causes air to be incorporated into the tank mixture shall be avoided. Mechanical, rather than hydraulic, agitation is recommended. The agitation system shall be started long enough before flow through the nozzles to ensure a uniform mixture at start of flow through the nozzles.

2.4 Pump. The pump shall not cause excessive wear on the abrasive particles. A diaphragm-type pump with pulsation dampener is recommended. Roller and centrifugal-type pumps should not be used. Excess flow from the pump that is returned to the tank should not pass through small orifices.