



Standard Guide for Quantitating Cell Viability Within Biomaterial Scaffolds¹

This standard is issued under the fixed designation F2739; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This guide is a resource of cell viability test methods that can be used to assess the number and distribution of viable and non-viable cells within porous and non-porous, hard or soft biomaterial scaffolds, such as those used in tissue engineered medical products (TEMPs).

1.2 In addition to providing a compendium of available techniques, this guide describes materials specific interactions with the cell assays that can interfere with accurate cell viability analysis, and includes guidance on how to avoid, and/or account for, scaffold material/cell viability assay interactions.

1.3 These methods can be used for 3-D scaffolds containing cells that have been cultured *in vitro* or for scaffold/cell constructs that are retrieved after implantation in living organisms.

1.4 This guide does not propose acceptance criteria based on the application of cell viability test methods.

1.5 The values stated in SI units are to be regarded as standard. No other units of measurement are included in this standard.

1.6 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

2. Referenced Documents

2.1 *ASTM Standards:*²

F748 Practice for Selecting Generic Biological Test Methods for Materials and Devices

F2149 Test Method for Automated Analyses of Cells—The Electrical Sensing Zone Method of Enumerating and

Sizing Single Cell Suspensions

F2315 Guide for Immobilization or Encapsulation of Living Cells or Tissue in Alginate Gels

3. Terminology

3.1 *Definitions:*

3.1.1 *non-viable cell, n*—a cell not meeting one or more of the criteria for viability given in 3.1.2.

3.1.2 *viable cell, n*—a cell capable of metabolic activity that is structurally intact with a functioning cell membrane.

4. Summary of Guide

4.1 It is the intent of this guide to provide a compendium of the commonly used methods for quantitating the number and distribution of viable and non-viable cells within, or on, a biomaterial scaffold, because cell viability is important parameter of tissue engineering products used to regenerate or repair lost or diseased tissue. The methods can be applied to cells residing within an intact 3-D scaffold or matrix (that is, non-destructive methods) or to cells that have been removed from the scaffold or matrix (that is, destructive methods).

4.2 Most of the methods originate from analysis of cell number on 2-D surfaces, but have been adapted for the analysis of cells within 3-D constructs that are typically used in regenerative medicine approaches. The mechanisms and the sensitivity of the assays are discussed. The limitations of the assays due to using standard curves generated from cells on 2-D surfaces are described in this document. In addition, the ways in which the biomaterial scaffold itself can affect the viability assays are described.

4.3 This guide describes combinations of test methods which, when used together, will ensure the most accurate measure of the number and distribution of viable and non-viable cells.

5. Significance and Use

5.1 The number and distribution of viable and non-viable cells within, or on the surface of, a biomaterial scaffold is one of several important characteristics that may determine *in vivo* product performance of cell/biomaterial constructs (see 5.7); therefore there is a need for standardized test methods to quantitate cell viability.

¹ This guide is under the jurisdiction of ASTM Committee F04 on Medical and Surgical Materials and Devices and is the direct responsibility of Subcommittee F04.43 on Cells and Tissue Engineered Constructs for TEMPs.

Current edition approved Aug. 1, 2008. Published September 2008. DOI: 10.1520/F2739-08.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

5.2 There are a variety of static and dynamic methods to seed cells on scaffolds, each with different cell seeding efficiencies. In general, static methods such as direct pipetting of cells on to scaffold surfaces have been shown to have lower cell seeding efficiencies than dynamic methods that push cells into the scaffold interior. Dynamic methods include: injection of cells into the scaffold, cell seeding on biomaterials contained in spinner flasks or perfusion chambers, or seeding that is enhanced by the application of centrifugal forces. The methods described in this guide can assist in establishing cell seeding efficiencies as a function of seeding method and for standardizing viable cell number within a given methodology.

5.3 As described in Guide [F2315](#), thick scaffolds or scaffolds highly loaded with cells lead to diffusion limitations during culture or implantation that can result in cell death in the center of the construct, leaving only an outer rim of viable cells. Spatial variations of viable cells such as this may be quantitated using the tests within this guide. The effectiveness of the culturing method or bioreactor conditions on the viability of the cells throughout the scaffold can also be evaluated with the methods described in this guide.

5.4 These test methods can be used to quantitate cells on hard or soft 3-D biomaterials, such as ceramics and polymer gels. The test methods also apply to cells seeded on porous coatings.

5.5 Test methods described in this guide may also be used to distinguish between proliferating and non-proliferating viable cells. Proliferating cells proceed through the DNA synthesis (S) phase and the mitosis (M) phase to produce two daughter cells. Non-proliferating viable cells are in some phase of the cell cycle, but are not necessarily proceeding through the cell cycle culminating in proliferation.

5.6 Viable cells may be under stress or undergoing apoptosis. Assays for evaluating cell stress or apoptosis are not addressed in this guide.

5.7 While cell viability is an important characteristic of a TEMP, the biological performance of a TEMP is dependant on additional parameters. Additional tests to evaluate and confirm the cell identity, protein expression, genetic profile, lineage progression, extent of differentiation, activation status, and morphology are recommended.

5.8 Fundamental biocompatibility testing of the scaffold material itself as described in Practice [F748](#) should be completed prior to using the biomaterial with cells.

6. Selection of Test Methods

6.1 [Table 1](#) is a compendium of methods that can be used to quantitate cell viability on surfaces or in biomaterial scaffolds. Importantly, a combination of the methods listed in [Table 1](#) is required to determine viable and non-viable (or live and dead) cells quantitatively, and additional tests must be completed to quantitate the subset of proliferating viable cells within the total number of viable cells. Proliferating cells are viable, but viable cells are not necessarily proliferating. Non-viable cells can be identified, even if they are not intact structurally or metabolically, by intact nuclei or dye entry into the cell through a disrupted cytoplasmic membrane.

6.2 The total number of cells, both alive and dead, within a 3-D construct is typically determined by DNA analysis ([7.2](#)) after the cells are removed destructively from the biomaterial scaffold and solubilized. Since many cell types adhere very well to a scaffold, significant cell lysis can occur during cell removal and simple manual counting of intact stained or unstained cells ([7.1](#)) is not very reliable.

TABLE 1 Methods for Quantitating Cell Viability

	Destructive (Requires cell removal from scaffold or matrix)	Non-destructive (Cells remain in scaffold or matrix during test)
I. Total Cell Number		
DNA assay	X	
Crystal violet	X	
II. Live Cell Number		
Metabolic assays	X	X
Tetrazolium salt uptake: MTT, MTS, WST, XTT	X	
Alamar Blue		X
Neutral Red	X	
Glucose Consumption	X	X
Cell proliferation (DNA synthesis)		
[3H] Thymidine or BrDu labeling	X	
Dye exclusion assays		
Trypan blue, erythrosin, and nigrosin	X	
III. Live/Dead Ratios		
Live/Dead assays using dual fluorescent stains	X	
for plasma membrane integrity		
Non-fluorescent dye exclusion assays	X	
IV. Imaging—density, morphology and spatial distributions of cells		
Histological sectioning	X	
Confocal microscopy	X	X
Scanning electron microscopy	X	