

Rubber, vulcanized — Determination of creep in compression or shear

ICS 83.060

National foreword

This British Standard was published by BSI. It is the UK implementation of ISO 8013:2006. It supersedes BS 903-A15:1990 which is withdrawn.

The UK participation in its preparation was entrusted to Technical Committee PRI/22, Physical testing of rubber.

A list of organizations represented on PRI/22 can be obtained on request to its secretary.

This publication does not purport to include all the necessary provisions of a contract. Users are responsible for its correct application.

Compliance with a British Standard cannot confer immunity from legal obligations.

This British Standard was published under the authority of the Standards Policy and Strategy Committee on 28 February 2007

© BSI 2007

ISBN 978 0 580 50267 5

Amendments issued since publication

Amd. No.	Date	Comments

INTERNATIONAL STANDARD

**ISO
8013**

Second edition
2006-10-01

Rubber, vulcanized — Determination of creep in compression or shear

*Caoutchouc vulcanisé — Détermination du fluage en compression ou
en cisaillement*



Reference number
ISO 8013:2006(E)

AVA Documents
Document Sharing Hub

Contents

Page

Foreword.....	iv
Introduction	v
1 Scope	1
2 Normative references	1
3 Terms and definitions.....	1
4 Apparatus	2
5 Test piece	7
6 Time-lapse between vulcanization and testing	8
7 Mechanical conditioning.....	9
8 Test temperature.....	9
9 Procedure	9
10 Calculation of results	10
11 Expression of results	13
12 Test report	13
Annex A (informative) Values of forces required for rubbers of different hardnesses	14

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 8013 was prepared by Technical Committee ISO/TC 45, *Rubber and rubber products*, Subcommittee SC 2, *Testing and analysis*.

This second edition cancels and replaces the first edition (ISO 8013:1988), which has been revised to update the normative references (ISO 471, ISO 3383, ISO 4648 and ISO 4661-1 have been replaced by ISO 23529 and ISO 1747 by ISO 1827).

Introduction

When a constant stress is applied to rubber, the deformation is not constant but increases gradually with time; this behaviour is called “creep”. Conversely, when rubber is subjected to a constant strain, a decrease in the stress in the material takes place; this behaviour is called “stress relaxation”.

The creep test is of particular interest where vulcanized rubbers are used to support a constant load, such as in bearings or mountings.

The processes responsible for creep may be physical or chemical in nature, and under all normal conditions both processes will occur simultaneously. However, at normal or low temperatures and/or short times, creep is dominated by physical processes, whilst at high temperatures and/or long times, chemical processes are dominant. In general, physical creep is found to be directly proportional to logarithmic time, and chemical creep to linear time; but great care must be taken in extrapolating time/creep curves in order to predict creep after periods considerably longer than those covered by the test, and in using tests at higher temperatures as accelerated tests to give information on creep at lower temperatures.

In addition to the need to specify the temperature- and time-intervals in a creep test, it is also necessary to specify the initial strain and the previous mechanical history of the test piece, since these may also influence the measured creep, particularly in rubbers containing filler.

blank