

JIS

JAPANESE
INDUSTRIAL
STANDARD

Translated and Published by
Japanese Standards Association

JIS B 7761-2: 2004

(ISO 5349-2 : 2001)

(JSME/JSA)

**Hand-transmitted vibration—
Part 2 : Practical guidance for
measurement at the workplace**

ICS 13.160

Reference number : JIS B 7761-2 : 2004 (E)

PROTECTED BY COPYRIGHT

Foreword

This translation has been made based on the original Japanese Industrial Standard established by the Minister of Economy, Trade and Industry through deliberations at the Japanese Industrial Standards Committee according to the proposal of establishing a Japanese Industrial Standard from The Japan Society of Mechanical Engineers (JSME)/Japanese Standards Association (JSA) with a draft of being attached, based on the provision of Article 12 Clause 1 of the Industrial Standardization Law.

This Standard has been made based on ISO 5349-2:2001 *Mechanical vibration—Measurement and evaluation of human exposure to hand-transmitted vibration—Part 2: Practical guidance for measurement at the workplace* for the purpose of making it easier to compare this Standard with International Standard; to prepare Japanese Industrial Standard conforming with International Standard; and to propose a draft of an International Standard which is based on Japanese Industrial Standard.

Attention is drawn to the possibility that some parts of this Standard may conflict with a patent right, application for a patent after opening to the public, utility model right or application for registration of utility model after opening to the public which have technical properties. The relevant Minister and the Japanese Industrial Standards Committee are not responsible for identifying the patent right, application for a patent after opening to the public, utility model right or application for registration of utility model after opening to the public which have the said technical properties.

JIS B 7761 consists of the following parts, under the general title "*Hand-transmitted vibration*":

— *Part 1: General requirements*

— *Part 2: Practical guidance for measurement at the workplace*

Date of Establishment: 2004-03-20

Date of Public Notice in Official Gazette: 2004-03-22

Investigated by: Japanese Industrial Standards Committee

Standards Board

Technical Committee on Testing and Measurement Technology

JIS B 7761-2: 2004, First English edition published in 2006-04

Translated and published by: Japanese Standards Association
4-1-24, Akasaka, Minato-ku, Tokyo, 107-8440 JAPAN

In the event of any doubts arising as to the contents,
the original JIS is to be the final authority.

© JSA 2006

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

Printed in Japan

PROTECTED BY COPYRIGHT

Contents

	Page
Introduction	1
1 Scope	1
2 Normative references	1
3 Terms and definitions and symbols	2
3.1 Terms and definitions	2
3.2 Symbols	3
4 Quantities to be evaluated	3
5 Preparation of the measurement procedure	3
5.1 General	3
5.2 Selection of operations to be measured	3
5.3 Organization of the measurements	4
5.4 Duration of vibration measurements	6
5.5 Estimation of daily vibration duration	7
6 Measurement of vibration magnitude	8
6.1 Measurement equipment	8
6.2 Sources of uncertainty in vibration measurement	14
6.3 Check and verification of the measurement chain	16
7 Uncertainty of evaluation of daily vibration exposure	16
7.1 Acceleration measurement uncertainty	16
7.2 Exposure time measurement uncertainty	17
7.3 Evaluation of uncertainties	17
8 Calculation of the daily vibration exposure	17
9 Information to be reported	18
Annex A (informative) Examples of measurement locations	21
Annex B (informative) Evaluation of vibration exposure over periods greater than one day	30
Annex C (informative) Mechanical filters	32
Annex D (informative) Guidance on mounting accelerometers	34
Annex E (informative) Examples of the calculation of daily vibration exposure	38
Bibliography	46

Hand-transmitted vibration—Part 2: Practical guidance for measurement at the workplace

Introduction This Japanese Industrial Standard has been prepared based on the first edition of ISO 5349-2 *Mechanical vibration—Measurement and evaluation of human exposure to hand-transmitted vibration—Part 2: Practical guidance for measurement at the workplace* published in 2001 without modifying the technical contents.

1 Scope This part of JIS B 7761 provides guidelines for the measurement and evaluation of hand-transmitted vibration at the workplace.

This part of JIS B 7761 describes the precautions to be taken to make representative vibration measurements and to determine the daily exposure time for each operation in order to calculate the 8-h energy-equivalent vibration total value (daily vibration exposure).

This part of JIS B 7761 provides a means to determine the relevant operations which should be taken into account when determining the vibration exposure.

This part of JIS B 7761 applies to all situations where people are exposed to vibration transmitted to the hand-arm system by hand-held or hand-guided machinery, vibrating workpieces, or controls of mobile or fixed machinery.

Remarks : The International Standard corresponding to this Standard is as follows.

In addition, symbols which denote the degree of correspondence in the contents between the relevant International Standard and JIS are IDT (identical), MOD (modified), and NEQ (not equivalent) according to ISO/IEC Guide 21.

ISO 5349-2:2001 *Mechanical vibration—Measurement and evaluation of human exposure to hand-transmitted vibration—Part 2: Practical guidance for measurement at the workplace* (IDT)

2 Normative references The following standards contain provisions which, through reference in this text, constitute provisions of this Standard. If the indication of the year of publication is given to these referred standards, only the edition of indicated year constitutes the provision of this Standard but the revision and amendment made thereafter do not apply. The normative references without the indication of the year of coming into effect or the year of publication apply only to the most recent edition (including amendments).

JIS B 0153 *Glossary of terms used in mechanical vibration and shock*

NOTE : ISO 2041:1990 *Vibration and shock—Vocabulary* is equivalent to the said standard.

JIS Z 8131 *Mechanical vibration and shock—Human exposure—Vocabulary*

NOTE : ISO 5805:1997 *Mechanical vibration and shock—Human exposure—Vocabulary* is equivalent to the said standard.

ISO 5349-1:2001 *Mechanical vibration—Measurement and evaluation of human exposure to hand-transmitted vibration—Part 1: General requirements*

ISO 8041 *Human response to vibration—Measuring instrumentation*

ISO 8662 (all parts) *Hand-held portable power tools—Measurement of vibrations at the handle*

3 Terms and definitions and symbols

3.1 Terms and definitions For the purposes of this part of JIS B 7761, the terms and definitions given in JIS B 0153 and JIS Z 8131 and the following apply.

3.1.1 hand-fed machine machine where the operator feeds workpieces to the working part of the machine, such that the vibration exposure is obtained through the hand-held workpiece

Example : band-saw, pedestal grinder

3.1.2 hand-guided machine machine which is guided by the operator with his hands, such that the vibration exposure is obtained through the handles, steering wheel or tiller

Example : ride-on lawn mower, powered pallet truck, swing grinder

3.1.3 hand-held workpiece workpiece which is held in the hand, such that vibration exposure is obtained through the hand-held workpiece rather than, or as well as, through the power tool handle

Example : casting held against a pedestal grinder, wood fed into a band-saw

3.1.4 hand-held power tool powered tool which is held in the hand

Example : electric drill, pneumatic chisel, chain saw

3.1.5 inserted tool interchangeable or replaceable attachment which fits into or onto a power tool or machine

Example : drill bit, chisel, chain saw chain, saw-blade, abrasive wheel

3.1.6 operation identifiable task for which a representative vibration magnitude measurement is made, this may be for the use of a single power tool, or hand-held workpiece type or for a single phase of a task

3.1.7 operator person using a hand-fed, hand-guided or hand-held machine or power tool

3.1.8 tool operation any period during which a power tool is operating and the operator is being exposed to hand-transmitted vibration

3.1.9 workpiece item being operated upon by a power tool

3.2 Symbols In this part of JIS B 7761, the following symbols are used:

- a_{hwi} single-axis root-mean-square (r.m.s.) value of the frequency-weighted hand-transmitted vibration for operation i, in m/s^2 . An additional suffix x, y or z is used to indicate the direction of the measurement, i.e. a_{hwix} , a_{hwy} and a_{hwiz}
- a_{hvi} vibration total value for operation i, in m/s^2
- $A(8)$ daily vibration exposure, in m/s^2
- $A_i(8)$ contribution of operation i to the daily vibration exposure, in m/s^2 (for convenience, this is referred to as the "partial vibration exposure")
- T_0 reference duration of 8 h (28 800 s)
- T_i total duration (per day) of vibration exposure to operation i.

4 Quantities to be evaluated There are two principal quantities to be evaluated for each operation i during exposure to vibration:

- the vibration total value a_{hvi} , expressed in metres per second squared (m/s^2); this value is calculated from the three single-axis root-mean-square values of the frequency-weighted hand-transmitted vibration a_{hwix} , a_{hwy} and a_{hwiz} ;
- the duration (per day) T_i of vibration exposure to operation i.

The principal parameter to be reported is the daily vibration exposure $A(8)$. This is calculated from the values of a_{hvi} and T_i for all operations i (see clause 8).

5 Preparation of the measurement procedure

5.1 General The work of an operator at a workplace is composed of a series of operations, some of which may be repeated. The vibration exposure may vary greatly from one operation to another, either due to the use of different power tools or machines or different modes of operation of one power tool or machine.

To evaluate daily vibration exposure, it is first necessary to identify the operations which are likely to contribute significantly to the overall vibration exposure. For each of these operations, it is then necessary to decide on procedures for measuring the vibration exposure. The methods to be used will depend on the characteristics of the work environment, the work pattern and the vibration source.

5.2 Selection of operations to be measured It is important to make measurements for all the power tools or workpieces which may give a significant contribution to the daily vibration exposure. To obtain a good picture of the average daily vibration exposure it is necessary to identify all

- a) sources of vibration exposure (i.e. the machines and tools being used);
- b) modes of operation of the power tool, e.g.:
 - chain saws may be idling, operating under load while cutting through a tree

- trunk, or operating under low load while cutting side branches,
- a power drill may be used in impactive or non-impactive modes and may have a range of speed settings available;
- c) changes in the operating conditions where this might affect vibration exposure, e.g.:
 - a road breaker being used initially on a hard concrete surface followed by use on the softer soil underneath,
 - a grinder being used initially for bulk metal removal followed by more intricate operations of cleaning and shaping;
- d) inserted tools which might affect vibration exposure, e.g.:
 - a sander may be used with a series of different grades of abrasive paper, ranging from coarse to fine,
 - a stonemason may use a pneumatic chisel with a range of different chisel bits.

In addition, it can be useful to obtain

- e) information from workers and supervisors on which situations they believe produce the highest vibration magnitude;
- f) estimates of the potential vibration hazards for each operation, using information from manufacturers on vibration emission values, see Annex A, or using published results of previous measurements on similar power tools.

5.3 Organization of the measurements The organization of measurements can be approached in four basic ways:

- a) **Long-term measurement of continuous tool operation** The operation time is long and continuous, and during this time the operator maintains contact with the vibrating surface. In this case the vibration measurement can be made over long periods during the normal use of the power tool. The operation may include changes in vibration magnitude, provided that they are part of the normal working procedure.

In addition to vibration magnitude information, the evaluation of daily vibration exposure requires an evaluation of the duration of exposure to vibration per day.

- b) **Long-term measurement of intermittent tool operation** The operation time is long but includes short breaks where there is no vibration exposure, however, during the operation and breaks the operator maintains contact with the (vibrating) surface. In this case the vibration measurement can be made over long periods during the normal use of the power tool, provided that any breaks in operation are part of the normal working procedure and that the operator does not lose contact with the power tool or hand-held workpiece, or significantly alter position of his hands on the power tool or hand-held workpiece.

In addition to vibration magnitude information, the evaluation of daily vibration

exposure requires an evaluation of the duration of exposure to the operation per day. In this case the duration of exposure to the operation includes the short breaks in vibration exposure and so will be longer than the duration of exposure to vibration.

- c) **Short-term measurement of intermittent tool operation** In many situations the hand is often taken off the power tool or hand-held workpiece, e.g. the power tool is put down, the hand is moved to a different part of the power tool, or another hand-held workpiece is picked up. In other situations, changes have to be made to the power tools being used, e.g. different abrasive belts or drill bits fitted or alternative power tools used. In these cases short-term measurements can only be made during each phase of the work operation.

In some cases it is difficult, or impossible, to get reliable measurements during the normal work process, due to the exposure durations being too short for measurement purposes. In this case measurements may be made during simulated work operations which artificially arrange longer uninterrupted exposures with work conditions as near to normal as possible.

In addition to vibration magnitude information, the evaluation of daily vibration exposure requires an evaluation of the exposure duration associated with each work phase.

- d) **Fixed-duration measurement of bursts of tool operation or single or multiple shocks** Some operations involve exposure to short-duration bursts of vibration exposure, this may be single or multiple shocks, such as riveting hammers, nail guns, etc., or bursts of exposure, such as powered impact wrenches. In such cases it is often difficult to make an evaluation of actual exposure times, although the number of bursts of vibration per day can be estimated. In this case measurements may be made over a fixed duration which includes one or more complete tool operations. The duration of measurement should include as little time before, between and after bursts of vibration as possible.

In addition to vibration magnitude information and the estimate of the number of bursts of vibration exposures per day, the evaluation of daily vibration exposure requires information on the measurement duration and the number of bursts of vibration during the measurement period.

- NOTES 1 In the case of exposing the worker to multiple single shocks or transient vibration (e.g. fastening tools), the method described in ISO 5349-1 may not be adequate and underestimate the severity of shock exposure. However, in the absence of a better method, ISO 5349-1 may be applied but this should be done with caution and be indicated in the information to be reported.
- 2 Where measurements of vibration magnitude are to be compared (e.g. to compare the vibration produced by two different power tool or inserted tool options) it is important to make measurements of continuous tool operation, i.e. with no breaks in vibration exposure.

5.4 Duration of vibration measurements

5.4.1 Measurement during normal working A measurement should be an average over a period which is representative of the typical use of a power tool, machine or process. Where possible, the measurement period should start when the worker's hands first contact the vibrating surface, and should finish when the contact is broken. This period may include variations in the vibration magnitude and may even include periods when there is no exposure.

Where possible, a series of sample measurements should be taken at different times of the day, and averaged, so that variations in vibration through the day are accounted for.

NOTE : The average vibration magnitude of a series of N vibration magnitude samples is given by

$$a_{hw} = \sqrt{\frac{1}{T} \sum_{j=1}^N a_{hwj}^2 t_j}$$

where

a_{hwj} is the measured vibration magnitude for sample j

t_j is the measurement duration of sample j

$$T = \sum_{j=1}^N t_j$$

Vibration exposures are often for short periods, which are repeated many times during a working day. Although measurements can be averaged over complete cycles of operation (including periods when the vibration source is switched off), normally it is only possible to average over the short period that the hand is in contact with the vibrating surface.

The minimum acceptable duration of measurements depends on the signal, instrumentation and operation characteristics. The total measuring time (i.e. the number of samples multiplied by the duration per measurement) should be at least 1 min. A number of shorter duration samples should be taken in preference to a single long duration measurement. For each operation, at least three samples should be taken.

Measurements of very short duration (e.g. not more than 8 s) are unlikely to be reliable, particularly in their evaluation of low-frequency components, and should be avoided where possible. Where very short duration measurements are unavoidable (e.g. certain types of pedestal grinding for which contact times can be very short), it is advisable to take many more than three samples to ensure a total sample time not less than 1 min.

5.4.2 Simulated work procedures Where measurements are not possible, or difficult, during normal tool operation then simulated work procedures can be used to simplify the vibration measurement process.

The main use of simulated work procedures is to achieve measurements over longer periods than could be allowed during normal production work. For example, the pedestal grinding of small castings may only last a few seconds per casting; rather than try to measure for short durations on many castings it may be possible to simulate the grinding on a small number of scrap castings, using each scrap casting many times.

Picking up, putting down or replacing the power tool or hand-held workpiece may disturb the measurement. These disturbances may also be avoided by measuring during simulated work procedures which can be designed to avoid any interruptions between operations.

5.5 Estimation of daily vibration duration The daily exposure duration for each vibration source shall be obtained. Often a typical daily vibration exposure time will be based on

- a measurement of the actual exposure time during a period of normal use (e.g. as evaluated over a complete work cycle, or during a typical 30 min period) and
- information on work rate (e.g. the number of work cycles per shift or the shift length).

The first of these will be a measurement to determine how long an operator is exposed to vibration, and from what source, during a specified period. Various techniques may be used, for example:

- use of a stopwatch;
- use of a dedicated data logger linked to power tool usage;
- analysis of video recordings;
- activity sampling.

The most reliable source of information on typical work rate is work records. However, it is important to ensure that the information is compatible with the information required for an evaluation of daily vibration exposure. For example, work records might give very accurate information on the number of completed work items at the end of each day, but where there is more than one operator, or unfinished work items at the end of a shift, this information may not be directly applicable to a vibration exposure evaluation.

Whichever method is used for vibration measurement, the total exposure time per day has to be found. Where the vibration has been averaged over a complete work cycle, the daily exposure time is simply the duration of the work cycle multiplied by the number of cycles per day. If a measurement has been made for a period while the hand is in contact with the vibrating surface, evaluate the total contact time per day.

Warning! In general, when operators are asked for information on their typical daily power tool usage, they will normally overestimate, giving an estimate of the period of time for which a power tool is used, including pauses in tool operation (e.g. breaks in tool operation between nuts when operating a nut runner or the time to prepare a new workpiece).

NOTE : ISO 5349-1 only provides a system for evaluating daily vibration exposure on one working day; it cannot be assumed that the method provided by ISO 5349-1 can be extrapolated to allow the averaging of exposures over periods greater than one day. However, in some situations it may be desirable to obtain an evaluation of exposure based on exposure information obtained over periods greater than one day. For example, in some types of work the amount of time using vibrating power tools changes significantly from one day to the next (e.g. industries such as construction or ship building and repair); it is then difficult, or impossible, to use observation or work records to obtain an indication of typical daily exposure times. Annex B gives examples of methods which have been used for evaluating vibration exposures over periods greater than one day.

6 Measurement of vibration magnitude

6.1 Measurement equipment

6.1.1 General Vibration measurement systems generally use accelerometers to detect the motion of the vibrating surface. The vibration signal from the accelerometer can be processed in a number of different ways to achieve a measure of the frequency-weighted acceleration.

Vibration measurements may be made using simple, single-unit vibration meters, featuring built-in frequency weightings and integrating facilities. These systems are designed primarily to evaluate the vibration exposure at the workplace; they are generally sufficient for most situations covered by this part of JIS B 7761. However, simple instrumentation may not be able to show errors associated with vibration measurement.

More sophisticated measurement systems are often based around some form of frequency analysis (e.g. one-third-octave or narrow band), they may use digital or analogue data recorders to store time information, they may use computer-based data acquisition and analysis techniques. These systems are more costly and complex to operate than the single-unit systems.

Where there is any doubt about the quality of the acceleration signal (e.g. DC-shift, see 6.2.4) it is useful to have information from frequency analysis. Frequency analysis will also provide information on any dominant frequencies, and harmonics, which may help to identify effective vibration control measures.

At the limits of application of ISO 5349-1 (e.g. repeated single shocks, dominant frequency components exceeding 1 250 Hz) any additional information available e.g. from more sophisticated measurement systems may be useful.

Minimum performance requirements (e.g. frequency weighting characteristics, tolerances, dynamic range, sensitivity, linearity and overload capacity) for appropriate measuring and analysing equipment are given in ISO 8041.

6.1.2 Accelerometers

6.1.2.1 General In general, the choice of accelerometer will be defined by the expected vibration magnitude, the required frequency range, the physical characteristics of the surface being measured and the environment in which they are to be used.

6.1.2.2 Vibration magnitude Hand-held machines can produce high vibration magnitudes. A pneumatic hammer, for example, may generate a maximum acceleration of 20 000 m/s² to 50 000 m/s². However, much of this energy is at frequencies well outside the frequency range used in this part of JIS B 7761. The accelerometer chosen for the measurement has therefore to be able to operate at these very high vibration magnitudes and yet still respond to the much lower magnitudes in the frequency range from 6.3 Hz to 1 250 Hz (one-third-octave band mid-frequencies). For the use of mechanical filters to suppress vibration at very high frequencies, see Annex C.

6.1.2.3 Frequency range Accelerometer selection will also be influenced by the fundamental resonance frequency of the accelerometer, this is a characteristic of the accelerometer. Information on the fundamental resonance frequency will be available from the accelerometer manufacturer. ISO 5348 recommends that the fundamental resonance frequency should be more than five times the maximum frequency of interest (for hand-transmitted vibration, this corresponds to 6 250 Hz). For piezoelectric accelerometers, the fundamental resonance frequency should normally be much higher, ideally greater than 30 kHz, to minimize the likelihood of DC-shift distortion (see 6.2.4).

NOTE : The fundamental resonance frequency of the accelerometer should not be confused with the resonance frequency of the accelerometer when mounted on a hand-held workpiece or power tool which is a characteristic of the whole accelerometer mounting system. In practice, the resonance of the mounted accelerometer on a hand-held workpiece or power tool will be substantially lower than the fundamental resonance frequency (see 6.1.4).

6.1.2.4 Mass influence When accelerometers are attached to a vibrating surface the vibration characteristics of that surface are altered. The lighter the accelerometer(s) the smaller the error introduced (see 6.1.5).

6.1.2.5 Environmental conditions When selecting accelerometers, particularly for use in harsh environments, it will be necessary to consider the accelerometer's sensitivity to temperature, humidity or other environmental factors (see ISO 8041).

6.1.3 Location of accelerometers Vibration measurements should be made at or near the surface of the hand (or hands) where the vibration enters the body. Preferably, the accelerometer should be located at the middle of the gripping zone (e.g. halfway along the width of the hand when gripping a power tool handle), it is at this location that the most representative evaluation of the vibration entering the hand is obtained. However, it is generally not possible to locate transducers at this point; the transducers will in-

interfere with the normal grip used by the operator.

Measurements directly under the hand are usually only possible using special mounting adaptors (see Annex D). Such adaptors should fit under the hand, or between the fingers. For most practical measurements, the accelerometers are mounted either side of the hand or on the underside of the tool handle adjacent to the middle of the hand. With adaptors which fit between the fingers, the transducers should be mounted as close as possible to the surface of the tool handle to minimize amplification of rotational vibration components. They should not have any structural resonances which would affect the measured vibration.

It is possible to get differences in vibration measurement across the width of the hand, particularly for hand-held power tools with side handles, such as angle grinders, and especially where these handles are flexibly mounted. In these cases it is recommended that two accelerometer positions are used, located at the sides of the hand; the average of the two vibration measurements is then used to estimate vibration exposure.

For many hand-held power tools, specific measurement locations and axes have been defined for the measurement of vibration emission by ISO 8662 and other International Standards; these measurement locations are summarized in Annex A as examples of measurement locations. The measurement locations defined in ISO 8662 are designed for a particular type of measurement (usually single axis only) and are not necessarily suitable for the evaluation of vibration exposure. However, in some circumstances it may be appropriate to ensure that workplace measurements of vibration are made using locations and axes compatible with those used for emission measurements.

6.1.4 Attaching accelerometers

6.1.4.1 General The accelerometers should be rigidly attached to the vibrating surface. Annex D gives details of some mounting methods. A method shall be chosen which gives an adequate fixing to the vibrating surface, does not interfere with the operation of the power tool and does not itself affect the vibration characteristics of the vibrating surface. The mounting method chosen will be dependent on the particular measurement situation, each method has its own advantages and disadvantages.

The mounting system should have a flat frequency response across the range of frequencies being measured, i.e. it should not attenuate or amplify and should not have any resonances in this frequency range. The mounting system should be securely fitted to the vibrating surface, and all fixings should be carefully checked before and after measurement.

The mounting of accelerometers on a power tool or hand-held workpiece is necessarily intrusive and will have some effect on how the operator works. The mounting of the transducers should be arranged so that the operator can work as normally as possible. It is important, prior to measurements, to observe how a power tool or hand-held workpiece is held, to identify the best location and orientation of the accelerometers.

The location (or locations) and orientation of the transducers should be reported.

It is very important to avoid interfering with the power tool controls or with the safe operation of a power tool or machine. It is often the case on power tools, that the best measurement location is where the on-off switch is positioned. Care shall be taken to ensure that the power tool controls are not (and will not become) impeded by transducers, mountings or cables.

6.1.4.2 Attaching to surfaces with resilient coatings When a power tool handle has a soft outer coating the vibration transmission properties of the coating will be dependent on the force with which the mounting system is attached. In such cases care shall be taken to ensure that the measurement of vibration is not affected by the resilient material. If the coating is not thought to be providing reduction in vibration exposure, either

- remove the resilient material from the area beneath the transducers, or
- fix the transducers using a force which fully compresses the resilient material.

In most cases this approach will be adequate. However, it does not account for the vibration transmission properties of the resilient coating.

Generally, resilient materials on power tool handles are not intended to provide vibration reduction but to provide a good grip surface. Any resilient coatings will not usually affect the frequency-weighted vibration magnitude.

If the resilient coating may be providing some reduction in vibration exposure, for example, if it is a thick layer of resilient material, then fix the transducer to an adaptor (see D.2.4) which is held against the vibrating surface by the normal hand grip of the operator (the adaptor may be held in position using adhesive tape wrapped lightly around the power tool handle and adaptor). This type of measurement is difficult, but it could give a better indication of the actual vibration exposure.

NOTE : It is possible for poorly selected resilient materials to amplify the vibration at certain frequencies.

6.1.4.3 Attaching to handles or gripping zones constructed of lightweight, flexible materials For power tools with handles or gripping zones constructed of lightweight, flexible materials, e.g. plastic side handle on some sanders and grinders, adhesive may be used to attach low-mass accelerometers to the surface of the material.

6.1.5 Accelerometer mass Fixing accelerometers to a vibrating surface will affect the way the surface vibrates. The greater the mass fitted to the surface, the greater the effect. If the total mass of accelerometer, or accelerometers, and mounting system is small compared to the mass of the power tool, power tool handle or hand-held work-piece it is fitted to (5 % or less), then the effect can be ignored.

NOTE : Practical triaxial measurement systems of 30 g or less have been achieved.

If there is any doubt about the extent of the effect of the transducer's mass then the following test should be used:

- a) Attach the accelerometer(s) to the power tool handle or hand-held workpiece and make a measurement of vibration magnitude.
- b) Repeat the measurement with an additional mass, similar to that of the accelerometer, separately attached to the power tool or hand-held workpiece, positioned next to the accelerometers.
- c) If the magnitude of the vibration from the two measurements is markedly different a lighter accelerometer or mounting system should be used.

6.1.6 Triaxial measurement Triaxial measurement of vibration, using the basicentric coordinate system defined in ISO 5349-1 is preferred. However, there are some situations where triaxial measurement may not be possible or necessary. In such situations ISO 5349-1 requires that an appropriate multiplication factor is applied to a single- or two-axis measurement result to give an estimated vibration total value.

The multiplication factor used should be between 1.0 for highly dominant single-axis tools and 1.7 where the measured axis represents the vibration in all three axes. (A vibration axis is dominant when both non-dominant axis vibration values are each less than 30 % of the dominant axis vibration value.) Where single-axis measurements are to be used, the single axis shall be the dominant axis.

Example 1 : Where the orientation of a workpiece is continually changing in the hands of the operator (e.g. the pedestal grinding of small components), one single-axis measurement may be sufficient to provide a representative vibration exposure estimate. The vibration total value is given by

$$a_{hv} = \sqrt{a_{hwx}^2 + a_{hwy}^2 + a_{hwz}^2}$$

In this example, the estimated vibration total value is to be calculated from one measured acceleration, $a_{hw, \text{measured}}$, which is assumed to be representative of the vibration in all three axes of the basicentric coordinate system, i.e.

$$\begin{aligned} a_{hv} &= \sqrt{a_{hw, \text{measured}}^2 + a_{hw, \text{measured}}^2 + a_{hw, \text{measured}}^2} \\ &= \sqrt{3} a_{hw, \text{measured}} = 1.73 a_{hw, \text{measured}} \end{aligned}$$

Therefore a multiplication factor of 1.73 (rounded to 1.7) should be used to give the estimated vibration total value. The estimated vibration total value will therefore be 1.7 times the measured single-axis vibration value.

Example 2 : Initial measurements on a road breaker show the vertical axis vibration is dominant and that the vibration in the other axes is each always less than 30 % of the acceleration in the dominant axis, $a_{hw, \text{dominant}}$. In this case the estimated vibration total value is given by

$$\begin{aligned} a_{hv} &= \sqrt{a_{hw, \text{dominant}}^2 + (0.3 a_{hw, \text{dominant}})^2 + (0.3 a_{hw, \text{dominant}})^2} \\ &= \sqrt{1 + 2 \times 0.3^2} a_{hw, \text{dominant}} = 1.086 a_{hw, \text{dominant}} \end{aligned}$$