WAGON TYPE	**COMMODITY**
OBA BASS Wooden door type	Portable Lighting Towers: VT1 Superlight RL 4000
Carrying Capacity: Each wagon has a carrying capacity of 30.50 tonnes. Gross laden weight 44.80 tonnes. Tare weight 14.30 tonnes For exact loading limits see individual wagon on TOPS	
Load Positioning : The wagon floor shall be clean of loose material and debris. Lighting towers shall be loaded evenly along the length of the wagon and centrally across the wagon. **VT1 Superlight** Maximum of 3 units, one at each end and one central. The lighting tower shall be fully retracted in the lowered position. The tower shall be in the transit position with the green arrows aligned and locked in position. The bulb units shall be folded so as the glass aspects face towards one another. All 4 stabilising legs shall be lowered and locked in position. Hand brakes shall be applied. Jockey wheel can be raised or lowered. Any other position will make the bulb aspects **'out of gauge'.** **RL 4000** – Max 2 units, one at each end of wagon. The lighting tower shall be in the lowered position and stowed. All 3 stabilising legs shall be lowered and locked in position. Hand brakes shall be applied. Jockey wheel can be raised or lowered.	
Stanchions: N/A	
Bolsters: N/A	
Dunnage: 75 mm x 75 mm timber dunnage of adequate length shall be nailed in position in front and rear of the lighting tower wheels. Timbers shall be one piece and should be long enough to chock both wheels of the same axle.	
Unsecured Loads: Not permitted	
Securing Equipment: Two hand ratchet tensioner throw over straps to be used per unit. Care shall be taken on the position of straps so as not to cause any damage to the units. Straps should pass between the door underside and wagon floor. (it may be necessary to open the doors to get the straps correctly positioned) Straps shall not be placed over the doors.	
Voids: N/A	
Doors/Sides: Doors shall be opened during loading and unloading. All doors to be fully closed and secured. Any excess movement of the door stanchions to be advised to the wagon owner prior to loading.	
Special Equipment: N/A	
Competency: Loader	
Safety: P.P.E. is to be worn at all times.	

Documents
Document Sharing Hub

Copyright Network Rail
Provided by IHS under license with Network Rail
No reproduction or networking permitted without license from IHS
Full document details: NR NR-L3-NDS-308-LMB1.4 ISSU 2012

Licensee=Weston Williamson/5989497001, User=sam, albett
Not for Resale, 03/27/2016 20:30:09 MDT







Blue generator is the VT1 Superlite

White generator is the RL 4000





Documents
Document Sharing Hub

Copyright Network Rail
Provided by IHS under license with Network Rail
No reproduction or networking permitted without license from IHS
Full document details: NR NR-L3-NDS-308-LMB1.4 ISSU 2012

Licensee=Weston Williamson/5989497001, User=sam, albett
Not for Resale, 03/27/2016 20:30:09 MDT