

Special Precautions for Fusing Saddle Fittings to Live PE Fuel Gas Mains Pressurized on the Basis of a 0.40 Design Factor

TN-20

2016



SPECIAL PRECAUTIONS FOR FUSING SADDLE FITTINGS TO LIVE PE FUEL GAS
MAINS PRESSURIZED ON THE BASIS OF A 0.40 DESIGN FACTOR

Contents

Foreword.....ii

1.0 Background 1

2.0 Precautions And Recommendations 2

 2.1 Precautions..... 2

 2.2 Recommendations..... 3