

Safety valves, gauges and fusible plugs for compressed air or inert gas installations —

Part 1: Code of practice for installation

UDC 621.51/.54:[531.787+536.522.2+621.646.28]

NO COPYING WITHOUT BSI PERMISSION EXCEPT AS PERMITTED BY COPYRIGHT LAW

BSI
Documents

AVA

Document Sharing Hub

Committees responsible for this British Standard

The preparation of this British Standard was entrusted by the Pressure Vessel Standards Committee (PVE/-) to Technical Committee PVE/12, upon which the following bodies were represented:

- Associated Offices Technical Committee
- Association of Shell Boilermakers
- British Compressed Air Society
- British Compressed Gases Association
- British Valve Manufacturers Association Ltd
- Combustion Engineering Association
- Electricity Supply Industry in England and Wales
- Energy Industries Council
- Engineering Equipment and Materials Users Association
- GAMBICA (BEAMA Ltd)
- Health and Safety Executive
- Institution of Mechanical Engineers
- Lloyds Register of Shipping
- Spring Research and Manufacturers Association
- Transmission and Distribution Association (BEAMA Ltd)
- Water Tube Boilermakers Association

The following body was also represented in the drafting of the standard, through subcommittees and panels:

Liquefied Petroleum Gas Industry Technical Association (UK)

This British Standard, having been prepared under the direction of the Pressure Vessel Standards Committee, was published under the authority of the Board of BSI and comes into effect on 27 February 1987

© BSI 02-1999

First published July 1943
First revision February 1950
Second revision July 1961
Third revision October 1976
Fourth revision, as Part 1, February 1987

The following BSI references relate to the work on this standard:
Committee reference PVE/12
Draft for comment 85/71476 DC

ISBN 0 580 15682 6

Amendments issued since publication

Amd. No.	Date of issue	Comments

Contents

	Page
Committees responsible	Inside front cover
Foreword	ii
Section 1. General	
1 Scope	1
2 Definitions	1
Section 2. Fittings excluding safety valves	
3 Pressure gauges	2
4 Fusible plugs	2
Section 3. Installation and maintenance of safety valves	
5 General recommendations	3
6 Set pressure	3
7 Mountings	3
8 Discharge pipework	3
9 Easing gear	3
10 Maintenance	3
Section 4. Useful information on safety valves complying with BS 6759-2	
11 Certified discharge capacity	4
12 Tolerances	4
Publications referred to	Inside back cover