

Building construction machinery and equipment — Pile driving and extracting equipment — Terminology and commercial specifications

ICS 01.040.91

National foreword

This British Standard reproduces verbatim ISO 11886:2002, including Technical Corrigendum April 2006 and implements it as the UK national standard. The UK participation in its preparation was entrusted to Technical Committee B/513, Construction equipment and plant, and site safety, which has the responsibility to:

- aid enquirers to understand the text;
- present to the responsible international/European committee any enquiries on the interpretation, or proposals for change, and keep the UK interests informed;
- monitor related international and European developments and promulgate them in the UK.

A list of organizations represented on this committee can be obtained on request to its secretary.

Cross-references

The British Standards which implement international publications referred to in this document may be found in the *BSI Catalogue* under the section entitled “International Standards Correspondence Index”, or by using the “Search” facility of the *BSI Electronic Catalogue* or of British Standards Online.

This publication does not purport to include all the necessary provisions of a contract. Users are responsible for its correct application.

Compliance with a British Standard does not of itself confer immunity from legal obligations.

This British Standard, having been prepared under the direction of the Building and Civil Engineering Sector Policy and Strategy Committee, was published under the authority of the Standards Policy and Strategy Committee on 3 September 2002

Summary of pages

This document comprises a front cover, an inside front cover, the ISO title page, pages ii to v, a blank page, pages 1 to 30, an inside back cover and a back cover.

The BSI copyright date displayed in this document indicates when the document was last issued.

Amendments issued since publication

Amd. No.	Date	Comments
16459 Corrigendum No. 1	30 June 2006	Modification of 4.2.1.1, 4.2.2.1, 4.2.2.2 and 4.2.3

© BSI 2006

ISBN 0 580 40322 X

INTERNATIONAL STANDARD

ISO
11886

First edition
2002-08-01

Building construction machinery and equipment — Pile driving and extracting equipment — Terminology and commercial specifications

*Machines et matériels pour la construction des bâtiments — Matériel de
battage et d'extraction — Terminologie et spécifications commerciales*



Reference number
ISO 11886:2002(E)

Contents		Page
Foreword		iv
Introduction.....		v
1	Scope.....	1
2	Normative references.....	1
3	Terms and definitions	1
4	Commercial specifications.....	6
4.1	General characteristics of piling equipment	6
4.2	Main characteristics of pile installation and extraction equipment	9
Annex A (informative) Examples of pile driving and extracting equipment and assemblies		15

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 3.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this International Standard may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 11886 was prepared by Technical Committee ISO/TC 195, *Building construction machinery and equipment*.

Annex A of this International Standard is for information only.

Introduction

This International Standard has been developed in order to unify terms, definitions and commercial specifications referring to machines and equipment for pile driving or extracting.

It is intended for use by designers, producers, dealers and users of pile driving/extracting machines. It can also be of use in discussions on further standardization activities.

Building construction machinery and equipment — Pile driving and extracting equipment — Terminology and commercial specifications

1 Scope

This International Standard specifies terms and definitions of the main types of mechanical equipment for pile driving/extracting, such as pile arrangements on the construction site, pulling, installation of piles at the point of driving, driving and extraction of piles, pile head crushing, etc. Machines for non-mechanical processing, such as the injection of small piles with supporting fluids, are not dealt with in this International Standard.

NOTE Annex A shows examples of pile driving and extracting equipment.

2 Normative references

The following normative documents contain provisions which, through reference in this text, constitute provisions of this International Standard. For dated references, subsequent amendments to, or revisions of, any of these publications do not apply. However, parties to agreements based on this International Standard are encouraged to investigate the possibility of applying the most recent editions of the normative documents indicated below. For undated references, the latest edition of the normative document referred to applies. Members of ISO and IEC maintain registers of currently valid International Standards.

ISO 11375:1998, *Building construction machinery and equipment — Terms and definitions*

ISO/TR 12603, *Building construction machinery and equipment — Classification*

EN 996, *Piling equipment — Safety requirements*

3 Terms and definitions

For the purposes of this International Standard, the terms and definitions given in ISO 11375 and the following apply.

3.1

piling equipment

complete assembly of machines and components designed for installation or extraction piles or other longitudinal elements

3.2

base carrier

carrier machine

machine that provides mobility for and supports the mass of the piling equipment, together with the pile

NOTE The carrier machine may also accommodate the necessary power source and controls of the piling equipment. It may be an adapted lift crane or earth-moving machine or other machine specifically designed or adapted for this purpose. There are crawler, wheel, rail-mounted and floating carriers. The carrier includes necessary mountings to connect the leader or other guiding system.

3.3

crawler-mounted carrier

machine whose mobility is achieved by mounting it on a tracked undercarriage

See Figures A.1, A.2 and A.3.

3.4

wheel-mounted carrier

machine whose mobility is achieved by mounting it on a wheel undercarriage

See Figures A.4 and A.5.

3.5

rail-mounted carrier

machine whose wheeled undercarriage runs on rails

See Figure A.6.

3.6

floating carrier

machine that is fixed to or can move on a floating pontoon

See Figure A.7.

3.7

leader

guiding system

structure for mounting of the pile installation and extracting equipment

NOTE The leader or other guiding system enables the pile installation and extracting equipment to be accurately guided and aligned with the pile. It allows full freedom of axial movement of pile installation and extracting equipment. Additionally it may provide guidance to the pile. The leader or guiding system may be attached to the carrier machine in number of ways for its mobility. Different designs of the leaders and guiding systems can be identified (e.g. direct-mounted, boom-supported, swinging, guide cage or free-riding).

3.8

direct-mounted leader

structure directly coupled to the carrier machine

NOTE The major weight of the leader, pile, etc., is taken by the leader attachment (see 3.13) near the bottom of the leader.

3.9

boom-supported leader

structure connected to the boom head of the carrier machine

NOTE 1 The leader may extend above the boom head of the carrier machine. The major weight of the leader, pile, etc., is taken by the leader attachment at its fixing with the boom head.

NOTE 2 A further steadying connection is made by another part of the leader attachment at the lower leader structure.

3.10

swinging leader

structure suspended from the carrier machine boom head

3.11

guide cage

structure that provides guidance to the pile installation or extraction equipment and allows some limited axial movement of it during piling operations

3.12**free-riding attachment**

part fixed within the structure of the pile installation or extracting equipment

NOTE The free-riding attachment comprises such parts as pile sleeves, legs, inserts and clamping devices (see 3.34).

3.13**leader attachment**

connection between the carrier machine and leader

NOTE Different connections can be used (e.g. universal joints, sliding or telescopic elements).

3.14**piling rig**

carrier machine complete with leader attachment and leader, but without the pile installation and other equipment

3.15**pile installation and extraction equipment**

machine designed to cause pile movement relative to the surrounding soil

NOTE 1 The movement is downwards for installation and upwards for extracting types of equipment.

NOTE 2 The machines for pile installation and extraction can be divided into three main groups: impacting, vibration and static types.

3.16**impact equipment**

machine that produces the striking energy by raising the striking mass and dropping it on the pile with the aim of energy transfer in a relatively short time

3.17**impact hammer**

machine that drives piles into the soil and operates according to the **impact equipment** (3.16) operation principle

NOTE The striking mass may impact on the pile directly or indirectly. In the case of indirect impact on the pile, there are interference assemblies between the striking mass and the pile, which may comprise an anvil together with any form of pile cap assembly (see 3.30 and 3.31). Depending on the power source, the following types of impact hammers can be identified: winch operated, steam/air operated, diesel or hydraulically powered and the others.

3.18**winch-operated impact hammer**

machine in which the striking mass is raised by a wire rope on a winch or similar means

See Figure A.8.

3.19**steam/air-operated impact hammer**

machine in which the striking mass is raised by air or steam pressure

See Figure A.9.

3.20**diesel-powered impact hammer**

machine in which the striking mass is raised by the expansion of gases resulting from the combustion of fuel and air

See Figure A.10.

NOTE Normally this is a fuel diesel engine, but kerosene, methanol or other fluids may also be used.

3.21

hydraulically powered impact hammer

machine in which the striking mass is raised by hydraulic pressure

See Figure A.11.

3.22

impact extractor

machine that withdraws piles from the soil and operates according to the impact equipment operation principle, using the upwards kinetic energy of a rising mass

See Figure A.15.

NOTE The striking energy of an extractor is derived from the upwards kinetic energy of a rising mass being transferred to the head of a pile by means of a linkage, wire rope connection or other mechanical means. Depending on the power source and operation method, the following type of impact extractors can be identified: hydraulic, pneumatic, steam/air, electric and using expansion of gases resulting from the combustion of fuel and air.

3.23

impact extractor/hammer

machine that combines the functions of driving and extracting piles and operates according to the impact equipment operation principle

NOTE Common designs of the impact hammer/extractor machines are powered and operated hydraulically and electrically.

3.24

vibrator for piling equipment

machine that generates unidirectional vibrations and is used to install or extract piles

See Figures A.12 to A.14.

NOTE In most instances the vibrations are vertical. Vibration can be produced by eccentric masses or other means, while a device, placed above the vibratory body dampens the vibrations for the protection of the supporting carrier. The element to be installed into or extracted from the ground is rigidly held under the vibratory gearbox by mean of one or several clamps. However, for units designed for annular grip, the clamping device can be located on the side(s) of the vibratory gearbox(es). The vibratory unit vibrates the element, which in turn vibrates the ground around it; ground particles can then move in relation to each other. Friction between the element and the soil is therefore reduced and the element is either driven by its own weight added to that of the vibrator or extracted by a pull from the carrier. Common designs of the vibrators are powered and operated hydraulically and electrically.

3.25

electric vibrator for piling equipment

electrically powered machine that generates unidirectional vibrations to install or extract piles

See Figure A.12.

3.26

hydraulic vibrator for piling equipment

hydraulically powered machine that generates unidirectional vibrations to install or extract piles

See Figures A.13 and A.14.

3.27

static pile pushing/pulling device

machine essentially designed for installing or extracting sheet piles by applying a steady force to the pile

See Figure A.16.

NOTE The force is applied by means of several hydraulic jacks that are clamped on a number of sheet piles that have previously been installed into the ground. A movable device equipped with one or several jacks clamped on one or several sheet piles to be installed or extracted uses the reaction from the structure to press those sheet piles into the ground or extract them from the ground.