

Ref:	NR/L3/MTC/II0219/01
Issue:	1
Date:	04/09/2010
Compliance date:	04/12/2010

Level 3 Module

Installation and Commissioning of Intelligent Infrastructure Remote Condition Monitoring Logger

Ref:	NR/L3/MTC/II0219/01
Issue:	1
Date:	04/09/2010
Compliance date:	04/12/2010

Contents

1 Purpose	3
2 Scope	3
3 Definitions	3
4 Roles and responsibilities	4
5 Approval	4
6 Prime use	5
7 Feasibility and design	5
8 Configuration	5
9 Installation	5
10 Commissioning	8
11 Calibration	10
Figure 1 – Installation process	7
Figure 2 – Commissioning process	9
Figure 3 – RACI chart	10

Ref:	NR/L3/MTC/II0219/01
Issue:	1
Date:	04/09/2010
Compliance date:	04/12/2010

1 Purpose

Intelligent Infrastructure Remote Condition Monitoring (II RCM) system is being implemented to provide information on the condition and potential faults on specified Assets on the Network Rail Infrastructure.

To ensure that the systems are used in a correct and consistent way, a suite of Standards has been produced to provide guidance and processes to be applied to the use and management of RCM systems.

This standard is one of the suite, which also includes standards for guidance on the Maintenance of Assets fitted with RCM, Installation of RCM equipment, Management of response to Alarms and Alerts from the Systems and Calibration of the equipment. In places, specific reference and instruction is included to apply to the system and equipment fitted by the II RCM project.

2 Scope

This module of NR/L3/MTC/II0219 specifies the process for the Installation and Commissioning of Loggers as part of the Intelligent Infrastructure Remote Condition (II RCM) Monitoring Programme.

It covers the required action and activity for the Installation and Commissioning of II RCM Loggers to be used with related software systems in order to monitor faults or degradation in function of the assets upon which they are fitted.

This applies to all II RCM installations meeting Intelligent Infrastructure except FTN/GSM-R systems that are managed by the Telecoms Engineering Centre (TEC) in Stoke. It excludes all RCM installations carried out by non-II project activities.

3 Definitions

For the purposes of this standard, the following terms and definitions apply.

Alarm

indication provided by the Intelligent Infrastructure Remote Condition Monitoring system which indicates the imminent failure of the asset

Alert

indication provided by the Intelligent Infrastructure Remote Condition Monitoring system that notifies reduced operational performance of the asset