


**MECANIQUE SUSPENSION GMP-PONT
SUSPENSION PONT
SUPPORT-ELEMENT ELASTIQUE PONT - 1ERE PARTIE**

Page 1/19

SANS RESTRICTION D'UTILISATION

① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩

DEFINITION GENERALE DES POSITIONS DES SUPPORTS PONT




⑪ ⑫ ⑬ ⑭ ⑮ ⑯ ⑰ ⑱ ⑲ ⑳

Rep	DESIGNATION FRANCAIS	
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		

1 2 3 4 5 6 7 8 9 10

DEFINITIONS COMPLEMENTAIRES



11 12 13 14 15 16 17 18 19 20

Rep	DESIGNATION FRANCAIS	
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		




Diagram showing a bridge support assembly with numbered callouts 1 through 20. The assembly includes a main support structure (15) with various mounting points and reinforcement. Callouts 1-10 are at the top, 11-16 are at the bottom, and 17-20 are on the right. Section labels include SECTION D, SECTION E, SECTION A, SECTION B, and SECTION C. A box labeled 'REPERES NON ILLUSTRÉS' points to callouts 11-14.		
Rep	DESIGNATION FRANCAIS	
1		
2		
3		
4		
5	FLASQUE G TRAVERSE SUPPORT PONT	
6	FLASQUE D TRAVERSE SUPPORT PONT	
7		
8		
9		
10		
11	MONTANT G TRAVERSE SUPPORT PONT	
12	MONTANT D TRAVERSE SUPPORT PONT	
13		
14		
15	TRAVERSE SUPPORT PONT ASS	
16		
17	SEMELLE TRAVERSE SUPPORT PONT	
18		
19	RENFORT TRAVERSE SUPPORT PONT	
20		

