

4th edition, January 2004

Original

I

Guidance on the automatic operation of level crossings

Directives applicables aux systèmes automatiques des passages à niveau

Richtlinien für den automatischen Betrieb von Bahnübergangs-Sicherungsanlagen



UNION INTERNATIONALE DES CHEMINS DE FER
INTERNATIONALER EISENBAHNVERBAND
INTERNATIONAL UNION OF RAILWAYS

Leaflet to be classified in Volumes :

IV - Operating

VII - Way and Works

Application :

With effect from 1 September 2003

All members of the International Union of Railways

Record of updates

1st edition, January 1955

This leaflet, numbered 731 in 1952 and corresponding to previous leaflet No. B 32, has been re-numbered 761 as from 1st January 1955

3rd edition, January 1967

4th edition, January 2004

Complete overhaul of leaflet

The person responsible for this leaflet is named in the UIC Code

Contents

Summary	1
1 - Basic parts of a level crossing system	2
1.1 - General	2
1.2 - System kernel	2
1.3 - Strike-in/out devices	2
1.4 - Warning signals	3
1.5 - Power supply	3
1.6 - Lineside signals	3
1.7 - Manual control	3
1.8 - Interface to an interlocking system	4
1.9 - Interface to an Automatic Train Protection system (ATP).....	4
1.10 -Diagnostics	4
2 - Conditions to be fulfilled by a level crossing system	5
2.1 - Warning time.....	5
2.2 - Intervals for closing barriers.....	5
2.3 - Failure management.....	5
2.4 - Additional features	6
2.5 - Wrong running direction.....	6
Bibliography	8

Summary

The leaflet gives an overview of basic parts of a level crossing system and of their functionality. It contains also recommendations for level crossing operation.

The leaflet consists of two main sections:

The first section lists basic physical parts of a level crossing system and describes their purpose.

The second section gives a functional overview including basic conditions to be fulfilled by a level crossing system. This section includes additional features to be considered when designing a level crossing system.