



Association of Textile, Apparel & Materials Professionals

AATCC takes no position respecting the validity of any patent rights asserted in connection with any item mentioned in this test method. Users of this test method are expressly advised that determination of the validity of any such patent rights, and the risk of infringement of such rights, are entirely their own responsibility.

This test method is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either reaffirmed or withdrawn. Your comments are invited either for revision of this test method or for additional procedures and should be addressed to the AATCC Technical Center. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing, you should make your views known to Diana A. Wyman, Technical Director, at the address shown below.

This test method is copyrighted by AATCC, PO Box 12215, Research Triangle Park, NC 27709 USA. Individual reprints (single or multiple copies) of this method may be obtained by contacting AATCC at the above address or tel: 919-549-3526; fax: 919-549-8933, or e-mail: orders@aatcc.org.

AATCC License Agreement: This test method is copyrighted by the American Association of Textile Chemists and Colorists (AATCC), PO Box 12215, 1 Davis Drive, Research Triangle Park, NC USA. All rights reserved.

AATCC grants you a license as follows: The right to download one electronic file of this AATCC test method for temporary storage on one computer for purposes of viewing, and/or printing one copy of the AATCC test method for individual use. Neither the electronic file nor the hard copy print may be reproduced in any way. In addition, the electronic file may not be distributed elsewhere over computer networks or otherwise. The hard copy print may only be distributed to other employees for their internal use within your organization.

This test method is not for resale.

Speckiness of Colorant Dispersions: Evaluation of

Developed in 1992 by AATCC Committee RA87; reaffirmed 1993, 2006; editorially revised 1994, 2004, 2008, 2009, 2010, 2013; revised 1995, 1996 (with title change); editorially revised and reaffirmed 2001, 2011. Technically equivalent to ISO 105-Z11.

1. Purpose and Scope

1.1 Agglomerates in colorant dispersions may become apparent as specks on a continuously dyed (padded) or on a printed fabric, especially when pale and light shades are produced.

1.2 This test method is used to determine speckiness, primarily of disperse dye, vat dye and pigment dispersions.

2. Principle

2.1 A dispersion of a dye is filtered through a polyester/cotton blend fabric.

2.2 The degree of speckiness is assessed visually.

3. Terminology

3.1 **disperse dye**, n.—a nonionic dye which is sparingly soluble in water and which has substantivity, when properly dispersed, for polyester, polyamide and some other manufactured polymeric fibers.

3.2 **dispersion**, n.—in *textile wet processing*, a suspension of very fine particles in a liquid phase.

3.3 **pigment**, n.—a colorant in particulate form which is insoluble in the substrate, but which can be dispersed in the substrate to modify its color.

3.4 **speck**, n.—a small particle, such as an agglomerate in a liquid dispersion, or a very small spot of dark color on a dyed substrate.

3.5 **speckiness**, n.—in *textile dyeing and printing*, the quality or state of containing specks.

3.6 **vat dye**, n.—a water-insoluble dye, usually containing keto groups, which is normally applied to the fiber from an alkaline aqueous solution of the reduced enol (leuco) form which is subsequently oxidized in the fiber to the insoluble form.

4. Safety Precautions

NOTE: These safety precautions are for information purposes only. The precautions are ancillary to the testing procedures and are not intended to be all inclusive. It is the user's responsibility to use

safe and proper techniques in handling materials in this test method. Manufacturers MUST be consulted for specific details such as material safety data sheets and other manufacturer's recommendations. All OSHA standards and rules must also be consulted and followed.

4.1 Good laboratory practices should be followed. Wear safety glasses in all laboratory areas.

4.2 All chemicals should be handled with care.

4.3 Use heat resistant gloves when working at hot air ovens and thermofixation devices.

4.4 Exposure to chemicals used in this procedure must be controlled at or below levels set by governmental authorities (e.g., Occupational Safety and Health Administration's [OSHA] permissible exposure limits [PEL] as found in 29 CFR 1910.1000; see web site: www.osha.gov for latest version). In addition, the American Conference of Governmental Industrial Hygienists (ACGIH) Threshold Limit Values (TLVs) comprised of time weighted averages (TLV-TWA), short term exposure limits (TLV-STEL) and ceiling limits (TLV-C) are recommended as a general guide for air contaminant exposure which should be met (see 12.1).

5. Apparatus and Materials

5.1 Filter cloth: 65/35 polyester/cotton, bleached woven broadcloth (shirting weight), approx. 240 × 240 mm square. A fabric of similar construction and of varying blend ratios may be used, but it must then be stated in the report.

5.2 Funnel, Buchner, polypropylene, 110 mm diameter. Cut out the perforated bottom smoothly and even with the rim using a knife or other suitable implement. Both parts are used in the test.

5.3 Filtering flask, heavy wall with side tabulation, 2 L.

5.4 Rubber stopper, 1 hole, to fit the filtering flask.

5.5 Stirrer, small propeller type, diameter approx. 20 mm, speed up to 2,200 rpm.

5.6 Dishes, evaporating, glass or porcelain, 1 L (approx. 150 mm diameter), three, for testing vat dyes.

5.7 Ovens.

5.7.1 Drying, without air circulation.

5.7.2 Thermofixation.

6. Reagents (only for testing vat dyes)

6.1 Sodium hydroxide (NaOH) (30%).

6.2 Sodium hydrosulfite conc. powder ($\text{Na}_2\text{S}_2\text{O}_4$).

6.3 Hydrogen peroxide (H_2O_2) (30%).

6.4 Acetic acid (CH_3COOH) (80%).

7. Preparation of Liquid Dispersions for Sampling

7.1 On prolonged storage, liquid dispersions tend to settle and may develop a more or less tacky sediment. It is imperative to ensure complete homogeneity of the dispersion prior to testing. Thoroughly mix dispersions in drums using a mechanical mixing device, such as a propeller stirrer or homogenizer. The liquid must be smooth and free of sediment and lumps before removing a sample for testing. Thoroughly shake laboratory samples to ensure that all dried material adhering to the cover and sides of the container is re-incorporated into the liquid. Then remove the cover and stir the sample either mechanically or by hand until all sediment and/or lumps are completely redispersed. Replace the cover and again shake the sample to ensure complete homogeneity. Test the sample immediately after homogenization. When storing the sample for future use, thoroughly clean the lid and the container lip prior to closure.

8. Procedure

8.1 Identify the filter cloth with the experiment or sample number in one of the corners and ensure that it is free of extraneous specks.

8.2 Clean and dry the funnel. Prepare the funnel assembly by placing the top part of the funnel upside down on a clean surface and drape the fabric over it as flat as possible with the identification mark facing down towards the surface. The side of the fabric with the identification will then be on top during filtration and is used for subsequent evaluation (see 9.1). Snap and press the bottom half of the funnel to the top half, causing the fabric to become a tight, smooth filter in the funnel.

8.3 Place the assembled funnel straight on the filtering flask using the rubber stopper to ensure that the funnel remains upright (and the filter fabric horizontal) during filtration and rinsing.

8.4 Weigh 7.5 ± 0.075 g of 100% powder or 15.0 ± 0.15 g of 50% liquid (or an equivalent weight of other concentrations) in a weighing cup and transfer to a 400 mL graduated beaker containing approx. 200 mL deionized or distilled water at room temperature. Rinse the weighing cup with water from a spray bottle.