

Australian Standard[®]

Zinc sulfide concentrates—Chemical analysis

Part 2: Determination of zinc—Ion-exchange/EDTA titrimetric method



This Australian Standard® was prepared by Committee MN-005, Copper, Lead, Zinc and Nickel Ores and Concentrates. It was approved on behalf of the Council of Standards Australia on 24 January 2008.
This Standard was published on 12 March 2008.

The following are represented on Committee MN-005:

- CSIRO Minerals
- Minerals Council of Australia

Additional Interests:

- Minerals industry analytical laboratories
-

This Standard was issued in draft form for comment as DR 07036.

Standards Australia wishes to acknowledge the participation of the expert individuals that contributed to the development of this Standard through their representation on the Committee and through the public comment period.

Keeping Standards up-to-date

Australian Standards® are living documents that reflect progress in science, technology and systems. To maintain their currency, all Standards are periodically reviewed, and new editions are published. Between editions, amendments may be issued.

Standards may also be withdrawn. It is important that readers assure themselves they are using a current Standard, which should include any amendments that may have been published since the Standard was published.

Detailed information about Australian Standards, drafts, amendments and new projects can be found by visiting **www.standards.org.au**

Standards Australia welcomes suggestions for improvements, and encourages readers to notify us immediately of any apparent inaccuracies or ambiguities. Contact us via email at **mail@standards.org.au**, or write to Standards Australia, GPO Box 476, Sydney, NSW 2001.

Australian Standard[®]

Zinc sulfide concentrates—Chemical analysis

Part 2: Determination of zinc—Ion-exchange/EDTA titrimetric method

Originated as AS 2678.2—1999.
Second edition 2008.

COPYRIGHT

© Standards Australia

All rights are reserved. No part of this work may be reproduced or copied in any form or by any means, electronic or mechanical, including photocopying, without the written permission of the publisher.

Published by Standards Australia GPO Box 476, Sydney, NSW 2001, Australia

ISBN 0 7337 8587 5

PREFACE

This Standard was prepared by the Standards Australia Committee MN-005, Copper, Lead, Zinc and Nickel Ores and Concentrates, to supersede AS 2678.2—1999.

The objective of this Standard is to provide those responsible for the analysis of zinc concentrates with a standardized method of determining zinc, supported by precision data obtained from an interlaboratory test program.

The objective of this revision is to adopt the latest edition of the corresponding International Standard.

This Standard is identical with, and has been reproduced from ISO 12739:2006, *Zinc sulfide concentrates—Determination of zinc—Ion-exchange/EDTA titrimetric method*.

As this Standard is reproduced from an International Standard, the following applies:

- (a) Its number appears on the cover and title page while the International Standard number appears only on the cover.
- (b) In the source text ‘this International Standard’ should read ‘this Australian Standard’.
- (c) A full point substitutes for a comma when referring to a decimal marker.
- (d) Substitute ‘L’ for ‘l’ as the unit for litres.

References to International Standards should be replaced by references to Australian Standards, as follows:

<i>Reference to International Standard</i>	<i>Australian Standard</i>
ISO	AS
9599 Copper, lead and zinc sulfide concentrates—Determination of hygroscopic moisture in the analysis sample—Gravimetric method	2816 Copper, lead and zinc sulfide concentrates—Determination of hygroscopic moisture in the analysis sample—Gravimetric method

Only international references that have been adopted as Australian Standards have been listed.

The terms ‘normative’ and ‘informative’ have been used in this Standard to define the application of the annex to which they apply. A ‘normative’ annex is an integral part of a Standard, whereas an ‘informative’ annex is only for information and guidance.

CONTENTS

	<i>Page</i>
1 Scope	1
2 Normative references	1
3 Principle	1
4 Reagents	1
5 Apparatus	3
6 Sample	3
6.1 Test sample	3
6.2 Test portion	3
7 Procedure	3
7.1 Number of determinations	3
7.2 Blank test	4
7.3 Dissolution of test portion	4
7.4 Preparation of the ion-exchange column	4
7.5 Adsorption of zinc on ion-exchange column	5
7.6 Elution of zinc from ion-exchange column	5
7.7 Titration	5
7.8 Determination of the titration factor of the EDTA standard volumetric solution	5
8 Expression of results	6
9 Precision	7
9.1 Expression of precision	7
9.2 Procedure for obtaining the final result	7
9.3 Between-laboratories precision	7
9.4 Check of trueness	8
10 Test report	9
Annex A (normative) Ion-exchange resins and columns	10
Annex B (normative) Procedure for the preparation and determination of the mass of a predried test portion	12
Annex C (normative) Determination of cadmium by atomic absorption spectrometry	14
Annex D (normative) Flowchart of the procedure for the acceptance of analytical values for test samples	16
Annex E (informative) Effect of potentially interfering elements	17
Annex F (informative) Derivation of precision equations	18
Bibliography	23

AUSTRALIAN STANDARD

Zinc sulfide concentrates—Chemical analysis

Part 2:

Determination of zinc—Ion-exchange/EDTA titrimetric method

WARNING — This International Standard may involve hazardous materials, operations and equipment. It is the responsibility of the user of this International Standard to establish appropriate health and safety practices and determine the applicability of regulatory limitations prior to use.

1 Scope

This International Standard specifies an ion-exchange/EDTA titrimetric method for the determination of the mass fraction of zinc in zinc concentrates. The method is applicable to zinc sulfide concentrates having a mass fraction of zinc in the range from 11 % to 62 %.

2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 385, *Laboratory glassware — Burettes*

ISO 648, *Laboratory glassware — One-mark pipettes*

ISO 1042, *Laboratory glassware — One-mark volumetric flasks*

ISO 3696, *Water for analytical laboratory use — Specification and test methods*

ISO 4787, *Laboratory glassware — Volumetric glassware — Methods for use and testing of capacity*

ISO 9599, *Copper, lead and zinc sulfide concentrates — Determination of hygroscopic moisture in the analysis sample — Gravimetric method*

3 Principle

The test portion of zinc concentrate is dissolved in hydrochloric, nitric and sulfuric acids. The acidity is adjusted to about 2 mol/l with respect to hydrochloric acid. Zinc is adsorbed on a strongly basic anion-exchange resin. Some interfering ions are removed by elution with 2 mol/l dilute hydrochloric acid. Zinc is eluted with an ammonia/ammonium chloride solution. Zinc is determined in the eluate by titration with EDTA at a pH of approximately 5,6 using xylenol-orange indicator.

4 Reagents

During the analysis, only reagents of recognized analytical grade and water that complies with grade 2 of ISO 3696 shall be used.

4.1 Zinc, 99,99 % minimum purity, free from oxide prior to use.

The surface of the metal may be cleaned by immersing the metal in hydrochloric acid (4.3) diluted 1 + 9, for 1 min, then washed well with water followed by an acetone rinse and dried in an oven at 50 °C.

4.2 Xylenol-orange indicator (0,1 % m/m)

Mix 0,1 g of the sodium salt of xylenol orange with 100 g of potassium nitrate crystals by gently grinding in a ceramic mortar with a pestle. Mixing is considered complete when the colour is uniform throughout.

4.3 Hydrochloric acid (ρ_{20} 1,16 g/ml to 1,19 g/ml)

4.4 Hydrochloric acid, diluted (1 + 1)

Add 500 ml of hydrochloric acid (4.3) to 500 ml of water.

4.5 Hydrochloric acid, diluted (1 + 5)

Add 100 ml of hydrochloric acid (4.3) to 500 ml of water.

4.6 Nitric acid (ρ_{20} 1,42 g/ml)

4.7 Nitric acid, diluted (1 + 1)

Add 500 ml of nitric acid (4.6) to 500 ml of water.

4.8 Sulfuric acid, diluted (1 + 1)

Add carefully and slowly, while stirring, 500 ml of sulfuric acid (ρ_{20} 1,84 g/ml) to 500 ml of water.

4.9 Sulfuric acid, diluted (1 + 100)

Add 20 ml of dilute sulfuric acid (4.8) to 1 000 ml of water.

4.10 Hydrofluoric acid (ρ_{20} 1,13 g/ml to 1,15 g/ml)

4.11 Ammonia solution, diluted (7 + 100)

Add 70 ml of aqueous ammonia solution (ρ_{20} 0,89 g/ml) to 1 000 ml of water.

4.12 Ammonia/ammonium chloride solution

Dissolve 20 g of ammonium chloride in 1 l of dilute ammonia solution (4.11).

4.13 Hydrochloric acid/ascorbic acid solution

Dissolve 0,25 g of ascorbic acid in 100 ml of dilute hydrochloric acid (4.5). Prepare fresh on the day of use.

4.14 Ammonium fluoride solution (50 g/l)

Dissolve 50 g of ammonium fluoride in water and dilute to 1 l.

4.15 Sodium thiosulfate solution (100 g/l)

Dissolve 100 g of sodium thiosulfate pentahydrate in water and dilute to 1 l.

4.16 Buffer solution (pH = 5,5)

Dissolve 250 g of ammonium acetate and 25 ml of concentrated acetic acid (ρ_{20} 1,05 g/ml) in water and dilute to 1 l.

4.17 Para-nitrophenol indicator solution (2 g/l)

Dissolve 0,2 g of para-nitrophenol in water and dilute to 100 ml.

4.18 EDTA standard volumetric solution (0,1 mol/l)

Dissolve 37,2 g of the di-sodium salt of ethylenediaminetetraacetic acid dihydrate (EDTA) in water and dilute to 1 l.

5 Apparatus

5.1 Class A volumetric glassware complying with ISO 385, ISO 648 and ISO 1042, and used in accordance with ISO 4787.

5.2 Balance, capable of being read to 0,1 mg.

5.3 Laboratory hotplate

5.4 Muffle furnace, capable of operating at 800 °C.

5.5 Platinum crucibles, of capacity 25 ml.

5.6 Ion exchange columns, having typical dimensions as shown in Annex A.

6 Sample

6.1 Test sample

Prepare an air-equilibrated test sample in accordance with ISO 9599.

NOTE A test sample is not required if predried test portions are to be used (see Annex B).

6.2 Test portion

Taking multiple increments, extract a test portion of 0,5 g, weighed to the nearest 0,1 mg, from the test sample, in such a manner that it is representative of the contents of the dish or tray. At the same time as the test portion is weighed, weigh test portions for the determination of hygroscopic moisture in accordance with ISO 9599.

Alternatively, the method specified in Annex B may be used to prepare predried test portions directly from the laboratory sample.

7 Procedure

7.1 Number of determinations

Carry out the determinations at least in duplicate, as far as possible under repeatability conditions, on each test sample.

NOTE Repeatability conditions exist where mutually independent test results are obtained with the same method on identical test material in the same laboratory, by the same operator using the same equipment, within short intervals of time.

7.2 Blank test

Determine a reagent blank. It is advisable to perform duplicate blank determinations every time an analysis is carried out on a laboratory sample. The blank samples are carried through the whole procedure, apart from where no laboratory sample test portion is required. The volume of EDTA titrant used is V_b .

7.3 Dissolution of test portion

Place the test portion in a 300 ml conical beaker. Add 25 ml of hydrochloric acid (4.3). Cover with a watch glass and heat the beaker and contents gently for 5 min.

Add 20 ml of dilute nitric acid (4.7) and 15 ml of dilute sulfuric acid (4.8). Heat and evaporate the solution to about 5 ml. Cool and add, with caution, about 50 ml of water and boil the solution.

Cool the solution to room temperature and filter it into a 300 ml beaker through a medium-speed cellulose filter paper. Wash the beaker and filter paper thoroughly with dilute sulfuric acid (4.9), collecting the washings in the same beaker.

If an acid-insoluble material is present, place the filter and insoluble residue in a platinum crucible (5.5) (see the last five paragraphs of this subclause) and gently reduce the paper to ashes in the muffle furnace (5.4) at 800 °C. Allow the crucible and residue to cool to ambient temperature. Add 2 ml of dilute sulfuric acid (4.8), 2 ml of nitric acid (4.6) and 2 ml of hydrofluoric acid (4.10) and evaporate the solution nearly to dryness. Cool and add water in small quantities to dissolve the soluble salts. Filter through a medium-speed cellulose filter paper and add the filtrate and washing solution to the initial solution obtained above as described in paragraphs 1 to 3.

Heat to evaporate the combined filtrates to a volume of 60 ml to 80 ml. Cool and add 16 ml of hydrochloric acid (4.3). Dilute to 100 ml with water.

If the sample contains lead, damage to the platinum crucible may occur. In this case, acid-insoluble material should be treated as follows.

Rinse the insoluble residues into a polytetrafluoroethylene beaker with a fine jet of water. Place the filter in a porcelain crucible and gently ash the paper in the muffle furnace at 600 °C to 700 °C. Allow the crucible to cool to ambient temperature.

Rinse the material from the crucible by washing with a small quantity of water into the polytetrafluoroethylene beaker used above. Add 2 ml of dilute sulfuric acid (4.8), 2 ml of nitric acid (4.6) and 2 ml of hydrofluoric acid (4.10), and evaporate the solution nearly to dryness.

Cool and add water in small quantities to dissolve the soluble salts. Filter through a medium-speed cellulose filter paper and add the filtrate and washing solution to the initial solution obtained above.

Should it be confirmed that the filter paper contains no zinc, the procedure of ashing the filter paper may be omitted.

7.4 Preparation of the ion-exchange column

Examples of ion-exchange columns that are suitable for use are shown in Annex A. Pack water-soaked cotton or glass-wool pads into the bottom of the column to a thickness of about 5 mm. This will retain resin in the column during use.

Soak the resin overnight in distilled water to make a slurry. With the stopcock open, carefully transfer the slurry into the column to form a settled bed. This resin bed is formed by about 16 ml of the swollen resin. Close the stopcock and put about a 5 mm thickness of water-soaked glass wool or cotton wool on top of the resin.

It is essential to ensure that the resin is covered by liquid at all times, because air trapped in a resin causes "channelling", i.e. uneven flow rate and poor efficiency in the ion exchanger. If air enters the resin bed, it is recommended that the column be emptied and then repacked.