



Designation: E 844 – 97

Standard Guide for Sensor Set Design and Irradiation for Reactor Surveillance, E 706(IIC)¹

This standard is issued under the fixed designation E 844; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ε) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This guide covers the selection, design, irradiation, post-irradiation handling, and quality control of neutron dosimeters (sensors), thermal neutron shields, and capsules for reactor surveillance neutron dosimetry.

1.2 The values stated in inch-pound units are to be regarded as the standard. The values given in parentheses are for information only.

1.3 *This standard does not purport to address all of the safety problems, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

2. Referenced Documents

2.1 ASTM Standards:

E 170 Terminology Relating to Radiation Measurements and Dosimetry²

E 261 Practice for Determining Neutron Fluence Rate, Fluence, and Spectra by Radioactivation Techniques²

E 854 Test Method for Application and Analysis of Solid State Track Recorder (SSTR) Monitors for Reactor Surveillance, E 706(IIIB)²

E 910 Test Method for Application and Analysis of Helium Accumulation Fluence Monitors for Reactor Vessel Surveillance, E 706(IIIC)²

E 1005 Test Method for Application and Analysis of Radiometric Monitors for Reactor Vessel Surveillance, E 706(IIIA)²

E 706(IIID) Analysis of Damage Monitors for Reactor Vessel Surveillance³

E 706(IIIE) Analysis of Temperature Monitors for Reactor Vessel Surveillance³

E 706(IIIE) Benchmark Testing of Reactor Vessel Dosimetry³

¹ This guide is under the jurisdiction of ASTM Committee E-10 on Nuclear Technology and Applications and is the direct responsibility of Subcommittee E10.05 on Nuclear Radiation Metrology.

Current edition approved June 10, 1997. Published May 1998. Originally published as E 844 – 81. Last previous edition E 844 – 86 (1991).

² Annual Book of ASTM Standards, Vol 12.02.

³ For standards that are in the draft stage and have not received an ASTM designation, see Section 5 as well as Figures 1 and 2 of Matrix E 706.

3. Terminology

3.1 Definitions:

3.1.1 *neutron dosimeter, sensor, monitor*—a substance irradiated in a neutron environment for the determination of neutron fluence rate, fluence, or spectrum, for example: radiometric monitor (RM), solid state track recorder (SSTR), helium accumulation fluence monitor (HAFM), damage monitor (DM), temperature monitor (TM).

3.1.2 *thermal neutron shield*—a substance (that is, cadmium, boron, gadolinium) that filters or absorbs thermal neutrons.

3.2 For definitions or other terms used in this guide, refer to Terminology E 170.

4. Significance and Use

4.1 In neutron dosimetry, a fission or non-fission dosimeter, or combination of dosimeters, can be used for determining a fluence-rate, fluence, or neutron spectrum, or both, in nuclear reactors. Each dosimeter is sensitive to a specific energy range, and, if desired, increased accuracy in a flux-spectrum can be achieved by the use of several dosimeters each covering specific neutron energy ranges.

4.2 A wide variety of detector materials is used for various purposes. Many of these substances overlap in the energy of the neutrons which they will detect, but many different materials are used for a variety of reasons. These reasons include available analysis equipment, different cross sections for different flux levels and spectra, preferred chemical or physical properties, and, in the case of radiometric dosimeters, varying requirements for different half-life isotopes, possible interfering activities, and chemical separation requirements.

5. Selection of Neutron Dosimeters and Thermal Neutron Shields

5.1 Neutron Dosimeters:

5.1.1 The choice of dosimeter material depends largely on the dosimetry technique employed, for example, radiometric monitors, helium accumulation monitors, track recorders, and damage monitors. At the present time, there is a wide variety of detector materials used to perform neutron dosimetry measurements. These are generally in the form of foils, wires, powders, and salts. The use of alloys is valuable for certain applications

ASTM E 844

such as (1) dilution of high cross-section elements, (2) preparation of elements that are not readily available as foils or wires in the pure state, and (3) preparation to permit analysis of more than one dosimeter material.

5.1.2 For neutron dosimeters, the reaction rates are usually deduced from the absolute gamma-ray radioanalysis (there exist exceptions, such as SSTRs, HAFMs, damage monitors). Therefore, the radiometric dosimeters selected must have gamma-ray yields known with good accuracy (>98 %). The half-life of the product nuclide must be long enough to allow for time differences between the end of the irradiation and the subsequent counting. Refer to Method E 1005 for nuclear decay and half-life parameters.

5.1.3 The neutron dosimeters should be sized to permit accurate analysis. The range of high efficiency counting equipment over which accurate measurements can be performed is restricted to several decades of activity levels (5 to 7 decades for radiometric and SSTR dosimeters, 8 decades for HAFMs). Since flux levels at dosimeter locations can range over 2 or 3 decades in a given experiment and over 10 decades between low power and high power experiments, the proper sizing of dosimeter materials is essential to assure accurate and economical analysis.

5.1.4 The estimate of radiometric dosimeter activity levels at the time of counting include adjustments for the decay of the product nuclide after irradiation as well as the rate of product nuclide buildup during irradiation. The applicable equation for such calculations is (in the absence of flux perturbations) as follows:

$$A = N_o \bar{\sigma} \phi \alpha (1 - e^{-\lambda t_1}) (e^{-\lambda t_2}) \quad (1)$$

where:

- A = expected disintegration rate (dps) for the product nuclide at the time of counting,
- N_o = number of target element atoms,
- ϕ = estimated flux density level,
- $\bar{\sigma}$ = spectral averaged cross section,
- α = product of the nuclide fraction and (if applicable) of the fission yield,
- $1 - e^{-\lambda t_1}$ = buildup of the nuclide during the irradiation period, t_1 ,
- $e^{-\lambda t_2}$ = decay after irradiation to the time of counting, t_2 , and
- λ = decay constant for the product nuclide.

5.1.5 For SSTRs and HAFMs, the same type of information as for radiometric monitors (that is, total number of reactions) is provided. The difference being that the end products (fission tracks or helium) require no time-dependent corrections and are therefore particularly valuable for long-term irradiations.

5.1.6 Fission detectors shall be chosen that have accurately known fission yields. Refer to Method E 1005.

5.1.7 In thermal reactors the correction for neutron self shielding can be appreciable for dosimeters that have highly absorbing resonances (see 6.1.1).

5.1.8 Dosimeters that produce activation or fission products (that are utilized for reaction rate determinations) with half-lives that are short compared to the irradiation duration should not be used. Generally, radionuclides with half-lives less than three times the irradiation duration should be avoided unless

there is little or no change in neutron spectral shape or fluence rate with time.

5.1.9 Tables 1-3 present various dosimeter elements. Listed are the element of interest, the nuclear reaction, and the available forms. For the intermediate energy region, the energies of the principal resonances are listed in order of increasing energy. In the case of the fast neutron energy region, the 95 % response ranges (an energy range that includes most of the response for each dosimeter is specified by giving the energies E_{05} below which 5 % of the activity is produced and E_{95} above which 5 % of the activity is produced) for the ^{235}U neutron thermal fission spectrum are included.

5.2 Thermal Neutron Shields:

5.2.1 Shield materials are frequently used to eliminate interference from thermal neutron reactions when resonance and fast neutron reactions are being studied. Cadmium is commonly used as a thermal neutron shield, generally 0.020 to 0.050 in. (0.51 to 1.27 mm) thick. However, because elemental cadmium (m.p. = 320°C) will melt if placed within the vessel of an operating water reactor, effective thermal neutron filters must be chosen that will withstand high temperatures of light-water reactors. High-temperature filters include cadmium oxide (or other cadmium compounds or mixtures), boron (enriched in the ^{10}B isotope), and gadolinium. The thicknesses of the shield material must be selected to account for burnout from high fluences.

5.2.2 In reactors, feasible dosimeters to date whose response range to neutron energies of 1 to 3 MeV includes the fission monitors ^{238}U , ^{237}Np , and ^{232}Th . These particular dosimeters must be shielded from thermal neutrons to reduce fission product production from trace quantities of ^{235}U , ^{238}Pu , and ^{239}Pu and to suppress buildup of interfering fissionable nuclides, for example, ^{238}Np and ^{238}Pu in the ^{237}Np dosimeter, ^{239}Pu in the ^{238}U dosimeter, and ^{233}U in the ^{232}Th dosimeter. Thermal neutron shields are also necessary for epithermal spectrum measurements in the 5×10^{-7} to 0.3-MeV energy range. Also, nickel dosimeters used for the fast activation reaction $^{58}\text{Ni}(n,p)^{58}\text{Co}$ must be shielded from thermal neutrons in nuclear environments having thermal fluence rates above $3 \times 10^{12} \text{ n} \cdot \text{cm}^{-2} \cdot \text{s}^{-1}$ to prevent significant loss of ^{58}Co and $^{58\text{m}}\text{Co}$.

TABLE 1 Dosimeter Elements—Thermal Neutron Region

Element of Interest	Nuclear Reaction	Available Forms
B	$^{10}\text{B}(n,\alpha)^7\text{Li}$	B, B ₄ C, B-Al, B-Nb
Co	$^{59}\text{Co}(n,\gamma)^{60}\text{Co}$	Co, Co-Al, Co-Zr
Cu	$^{63}\text{Cu}(n,\gamma)^{64}\text{Cu}$	Cu, Cu-Al, Cu(NO ₃) ₂
Au	$^{197}\text{Au}(n,\gamma)^{198}\text{Au}$	Au, Au-Al
In	$^{115}\text{In}(n,\gamma)^{116\text{m}}\text{In}$	In, In-Al
Fe	$^{58}\text{Fe}(n,\gamma)^{59}\text{Fe}$	Fe
Fe	$^{54}\text{Fe}(n,\gamma)^{55}\text{Fe}$	Fe
Li	$^6\text{Li}(n,\alpha)^3\text{H}$	LiF, Li-Al
Mn	$^{55}\text{Mn}(n,\gamma)^{56}\text{Mn}$	alloys
Ni	$^{58}\text{Ni}(n,\gamma)^{59}\text{Ni}$, ^{56}Fe	Ni
Pu	$^{239}\text{Pu}(n,f)\text{FP}$	PuO ₂ , alloys
Sc	$^{45}\text{Sc}(n,\gamma)^{46}\text{Sc}$	Sc, Sc ₂ O ₃
Ag	$^{109}\text{Ag}(n,\gamma)^{110\text{m}}\text{Ag}$	Ag, Ag-Al, AgNO ₃
Na	$^{23}\text{Na}(n,\gamma)^{24}\text{Na}$	NaCl, NaF, NaI
Ta	$^{181}\text{Ta}(n,\gamma)^{182}\text{Ta}$	Ta, Ta ₂ O ₅
U (enriched)	$^{235}\text{U}(n,f)\text{FP}$	U, U-Al, UO ₂ , U ₂ O ₅ , alloys



Documents

Document Sharing Hub



TABLE 2 Dosimeter Elements—Intermediate Neutron Region

Energy of Principal Resonance, eV (17)	Dosimetry Reactions	Element of Interest	Available Forms
^A	⁶ Li(n,α) ³ H	Li	LiF, Li-Al
^A	¹⁰ B(n,α) ⁷ Li	B	B, B ₄ C, B-Al, B-Nb
^A	⁵⁸ Ni(n,γ) ⁵⁹ Ni(n,α) ⁵⁶ Fe	Ni	Ni
1.457	¹¹⁵ In(n,γ) ^{116m} In	In	In, In-Al
4.28	¹⁸¹ Ta(n,γ) ¹⁸² Ta	Ta	Ta, Ta ₂ O ₅
4.906	¹⁹⁷ Au(n,γ) ¹⁹⁸ Au	Au	Au, Au-Al
5.19	¹⁰⁹ Ag(n,γ) ^{110m} Ag	Ag	Ag, Ag-Al, AgNO ₃
21.806	²³² Th(n,γ) ²³³ Th	Th	Th, ThO ₂ , Th(NO ₃) ₄
^B	²³⁵ U(n,f)FP	U	U, U-Al, UO ₂ , U ₃ O ₈ , alloys
132	⁵⁹ Co(n,γ) ⁶⁰ Co	Co	Co, Co-Al, Co-Zr
1038	⁵⁸ Fe(n,γ) ⁵⁹ Fe	Fe	Fe
337.3	⁵⁵ Mn(n,γ) ⁵⁶ Mn	Mn	alloys
579	⁶³ Cu(n,γ) ⁶⁴ Cu	Cu	Cu, Cu-Al, Cu(NO ₃) ₂
0.2956243	²³⁹ Pu(n,f)FP	Pu	PuO ₂ , alloys
2810	²³ Na(n,γ) ²⁴ Na	Na	NaCl, NaF, NaI
3295	⁴⁵ Sc(n,γ) ⁴⁶ Sc	Sc	Sc, Sc ₂ O ₃
7788	⁵⁴ Fe(n,γ) ⁵⁵ Fe	Fe	Fe

^AThis reaction has no resonance that contributes in the intermediate energy region and the principle resonance has negative energy (i.e. the cross section is 1/v).

^BMany resonances contribute in the 1 – 100 eV region for this reaction.

TABLE 3 Dosimeter Elements—Fast Neutron Region

Dosimetry Reactions	Element of Interest	Energy Response Range (MeV) ^{A,B}			Cross Section Uncertainty (%) ^{A,C}	Available Forms
		Low E ₀₅	Median E ₅₀	High E ₉₅		
²³⁷ Np(n,f)FP	Np	0.684	1.96	5.61	9.33	Np ₂ O ₃ , alloys
¹⁰³ Rh(n,n') ^{103m} Rh	Rh	0.731	2.25	5.73	3.1	Rh
⁹³ Nb(n,n') ^{93m} Nb	Nb	0.951	2.57	5.79	3.06	Nb, Nb ₂ O ₅
¹¹⁵ In(n,n') ^{115m} In	In	1.12	2.55	5.86	2.17	In, In-Al
¹⁴ N(n,α) ¹¹ B	N	1.75	3.39	5.86	—	TiN, ZrN, NbN
²³⁸ U(n,f)FP	U (depleted)	1.44	2.61	6.69	0.53	U, U-Al, UO ₃ , U ₃ O ₈ , alloys
²³² Th(n,f)FP	Th	1.45	2.79	7.21	5.09	Th, ThO ₂
⁹ Be(n,α) ⁶ Li	Be	1.59	2.83	5.26	—	Be
⁴⁷ Ti(n,p) ⁴⁷ Sc	Ti	1.70	3.63	7.67	2.17	Ti
⁵⁸ Ni(n,p) ⁵⁸ Co	Ni	1.98	3.94	7.51	2.43	Ni, Ni-Al
⁵⁴ Fe(n,p) ⁵⁴ Mn	Fe	2.27	4.09	7.54	2.17	Fe
³² S(n,p) ³² P	S	2.28	3.94	7.33	4.0	CaSO ₄ , Li ₂ SO ₄
³² S(n,α) ²⁹ Si	S	1.65	3.12	6.06	—	Cu ₂ S, PbS
⁵⁸ Ni(n,α) ⁵⁵ Fe	Ni	2.74	5.16	8.72	—	Ni, Ni-Al
⁴⁶ Ti(n,p) ⁴⁶ Sc	Ti	3.70	5.72	9.43	2.46	Ti
⁵⁶ Fe(n,p) ⁵⁶ Mn	Fe ^D	5.45	7.27	11.3	2.33	Fe
⁵⁶ Fe(n,α) ⁵³ Cr	Fe	5.19	7.53	11.3	—	Fe
⁶³ Cu(n,α) ⁶⁰ Co	Cu ^E	4.53	6.99	11.0	2.85	Cu, Cu-Al
²⁷ Al(n,α) ²⁴ Na	Al	6.45	8.40	11.9	1.40	Al, Al ₂ O ₃
⁴⁸ Ti(n,p) ⁴⁸ Sc	Ti	5.92	8.06	12.3	6.66	Ti
⁴⁷ Ti(n,α) ⁴⁴ Ca	Ti	2.80	5.10	9.12	—	Ti
⁶⁰ Ni(n,p) ⁶⁰ Co ^F	Ni ^E	4.72	6.82	10.8	10.3	Ni, Ni-Al
⁵⁵ Mn(n,2n) ⁵⁴ Mn	Mn ^G	11.0	12.6	15.8	13.4	alloys

^AEnergy response range was derived using the ENDF/B-VI²³⁵U fission spectrum, reference (17), MT = 9228, MF = 5, MT = 18. The cross section and associated covariance sources are identified in standard E 1018 and in Reference (18).

^BOne half of the detector response occurs below an energy given by E₅₀; 95 % of the detector response occurs below E₉₅ and 5 % below E₀₅.

^CUncertainty metric only reflects that component due to the knowledge of the cross section and is reported at the 1σ level.

^DLow manganese content necessary.

^ELow cobalt content necessary.

^FThis reaction does not appear in the ENDF/B-VI evaluation. The JENDL evaluation (19) was used.

^GLow iron content necessary.

by thermal neutron burnout (1).⁴

6. Design of Neutron Dosimeters, Thermal Neutron Shields, and Capsules

6.1 *Neutron Dosimeters*—Procedures for handling dosimeter materials during preparation must be developed to ensure

personnel safety and accurate nuclear environment characterization. During dosimeter fabrication, care must be taken in order to achieve desired neutron flux results, especially in the case of thermal and resonance-region dosimeters. A number of factors must be considered in the design of a dosimetry set for each particular application. Some of the principal ones are discussed individually as follows:

6.1.1 *Self-Shielding of Neutrons*—The neutron self-shielding phenomenon occurs when high cross-section atoms in the outer layers of a dosimeter reduce the neutron flux and

⁴ The boldface number in parentheses refers to the list of references at the end of the guide.