



BSI Standards Publication

Determination of certain substances in electrotechnical products

Part 3-1: Screening — Lead, mercury, cadmium, total chromium and total bromine by X-ray fluorescence spectrometry

National foreword

This British Standard is the UK implementation of EN 62321-3-1:2014.

It is identical to IEC 62321-3-1:2013.

Together with BS EN 62321-1:2013, BS EN 62321-2:2014, BS EN 62321-3-2:2014, BS EN 62321-4:2014, BS EN 62321-5:2014, BS EN 62321-7-1, BS EN 62321-7-2 and BS EN 62321-8 it supersedes BS EN 62321:2009, which will be withdrawn upon publication of all parts of the BS EN 62321 series.

The UK participation in its preparation was entrusted to Technical Committee GEL/111, Electrotechnical environment committee.

A list of organizations represented on this committee can be obtained on request to its secretary.

This publication does not purport to include all the necessary provisions of a contract. Users are responsible for its correct application.

© The British Standards Institution 2014.

Published by BSI Standards Limited 2014

ISBN 978 0 580 71853 3

ICS 13.020; 43.040.10

Compliance with a British Standard cannot confer immunity from legal obligations.

This British Standard was published under the authority of the Standards Policy and Strategy Committee on 31 May 2014.

Amendments/corrigenda issued since publication

Date	Text affected
------	---------------

EUROPEAN STANDARD
NORME EUROPÉENNE
EUROPÄISCHE NORM

EN 62321-3-1

April 2014

ICS 13.020; 43.040.10

Supersedes EN 62321:2009 (partially)

English version

**Determination of certain substances in electrotechnical products -
Part 3-1: Screening -
Lead, mercury, cadmium, total chromium and total bromine by X-ray
fluorescence spectrometry
(IEC 62321-3-1:2013)**

Détermination de certaines substances
dans les produits électrotechniques -
Partie 3-1: Méthodes d'essai -
Plomb, du mercure, du cadmium, du
chrome total et du brome total par la
spectrométrie par fluorescence X
(CEI 62321-3-1:2013)

Verfahren zur Bestimmung von
bestimmten Substanzen in Produkten der
Elektrotechnik -
Teil 3-1: Screening -
Blei, Quecksilber, Cadmium,
Gesamtchrom und Gesamtbrom durch
Röntgenfluoreszenz-Spektrometrie
(IEC 62321-3-1:2013)

This European Standard was approved by CENELEC on 2013-11-15. CENELEC members are bound to comply with the CEN/CENELEC Internal Regulations which stipulate the conditions for giving this European Standard the status of a national standard without any alteration.

Up-to-date lists and bibliographical references concerning such national standards may be obtained on application to the CEN-CENELEC Management Centre or to any CENELEC member.

This European Standard exists in three official versions (English, French, German). A version in any other language made by translation under the responsibility of a CENELEC member into its own language and notified to the CEN-CENELEC Management Centre has the same status as the official versions.

CENELEC members are the national electrotechnical committees of Austria, Belgium, Bulgaria, Croatia, Cyprus, the Czech Republic, Denmark, Estonia, Finland, Former Yugoslav Republic of Macedonia, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, the Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey and the United Kingdom.

CENELEC

European Committee for Electrotechnical Standardization
Comité Européen de Normalisation Electrotechnique
Europäisches Komitee für Elektrotechnische Normung

CEN-CENELEC Management Centre: Avenue Marnix 17, B - 1000 Brussels

© 2014 CENELEC - All rights of exploitation in any form and by any means reserved worldwide for CENELEC members.

Ref. No. EN 62321-3-1:2014 E

 **Documents**
Document Sharing Hub

Foreword

The text of document 111/298/FDIS, future edition 1 of IEC 62321-3-1, prepared by IEC/TC 111 "Environmental standardization for electrical and electronic products and systems" was submitted to the IEC-CENELEC parallel vote and approved by CENELEC as EN 62321-3-1:2014.

The following dates are fixed:

- latest date by which the document has to be implemented at national level by publication of an identical national standard or by endorsement (dop) 2014-10-25
- latest date by which the national standards conflicting with the document have to be withdrawn (dow) 2016-11-15

EN 62321-3-1:2014 is a partial replacement of EN 62321:2009, forming a structural revision and generally replacing Clauses 6 and Annex D.

Future parts in the EN 62321 series will gradually replace the corresponding clauses in EN 62321:2009. Until such time as all parts are published, however, EN 62321:2009 remains valid for those clauses not yet re-published as a separate part.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. CENELEC [and/or CEN] shall not be held responsible for identifying any or all such patent rights.

Endorsement notice

The text of the International Standard IEC 62321-3-1:2013 was approved by CENELEC as a European Standard without any modification.

Annex ZA

(normative)

Normative references to international publications with their corresponding European publications

The following documents, in whole or in part, are normatively referenced in this document and are indispensable for its application. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

NOTE When an international publication has been modified by common modifications, indicated by (mod), the relevant EN/HD applies.

<u>Publication</u>	<u>Year</u>	<u>Title</u>	<u>EN/HD</u>	<u>Year</u>
IEC 62321-1	-	Determination of certain substances in electrotechnical products - Part 1: Introduction and overview	EN 62321-1	-
IEC 62321-2	-	Determination of certain substances in electrotechnical products - Part 2: Disassembly, disjunction and mechanical sample preparation	EN 62321-2	-
ISO/IEC Guide 98-1	-	Uncertainty of measurement - Part 1: Introduction to the expression of uncertainty in measurement	-	-

CONTENTS

INTRODUCTION.....	7
1 Scope.....	8
2 Normative references	10
3 Terms, definitions and abbreviations	10
4 Principle	10
4.1 Overview	10
4.2 Principle of test	11
4.3 Explanatory comments	11
5 Apparatus, equipment and materials.....	12
5.1 XRF spectrometer	12
5.2 Materials and tools	12
6 Reagents.....	12
7 Sampling	12
7.1 General	12
7.2 Non-destructive approach.....	12
7.3 Destructive approach.....	12
8 Test procedure	13
8.1 General	13
8.2 Preparation of the spectrometer	13
8.3 Test portion	14
8.4 Verification of spectrometer performance	14
8.5 Tests	15
8.6 Calibration.....	15
9 Calculations	16
10 Precision	17
10.1 General	17
10.2 Lead.....	17
10.3 Mercury.....	17
10.4 Cadmium.....	17
10.5 Chromium.....	18
10.6 Bromine.....	18
10.7 Repeatability statement for five tested substances sorted by type of tested material.....	18
10.7.1 General	18
10.7.2 Material: ABS (acrylonitrile butadiene styrene), as granules and plates	18
10.7.3 Material: PE (low density polyethylene), as granules	19
10.7.4 Material: PC/ABS (polycarbonate and ABS blend), as granules	19
10.7.5 Material: HIPS (high impact polystyrene)	19
10.7.6 Material: PVC (polyvinyl chloride), as granules	19
10.7.7 Material: Polyolefin, as granules	19
10.7.8 Material: Crystal glass	20
10.7.9 Material: Glass	20
10.7.10 Material: Lead-free solder, chips.....	20

10.7.11 Material: Si/Al Alloy, chips	20
10.7.12 Material: Aluminum casting alloy, chips	20
10.7.13 Material: PCB – Printed circuit board ground to less than 250 µm	20
10.8 Reproducibility statement for five tested substances sorted by type of tested material	20
10.8.1 General	20
10.8.2 Material: ABS (Acrylonitrile butadiene styrene), as granules and plates	21
10.8.3 Material: PE (low density polyethylene), as granules	21
10.8.4 Material: PC/ABS (Polycarbonate and ABS blend), as granules	21
10.8.5 Material: HIPS (high impact polystyrene)	21
10.8.6 Material: PVC (polyvinyl chloride), as granules	22
10.8.7 Material: Polyolefin, as granules	22
10.8.8 Material: Crystal glass	22
10.8.9 Material: Glass	22
10.8.10 Material: Lead-free solder, chips	22
10.8.11 Material: Si/Al alloy, chips	22
10.8.12 Material: Aluminum casting alloy, chips	22
10.8.13 Material: PCB – Printed circuit board ground to less than 250 µm	22
11 Quality control	23
11.1 Accuracy of calibration	23
11.2 Control samples	23
12 Special cases	23
13 Test report	23
Annex A (informative) Practical aspects of screening by X-ray fluorescence spectrometry (XRF) and interpretation of the results	25
Annex B (informative) Practical examples of screening with XRF	31
Bibliography	40
Figure B.1 – AC power cord, X-ray spectra of sampled sections	32
Figure B.2 – RS232 cable and its X-ray spectra	33
Figure B.3 – Cell phone charger shown partially disassembled	34
Figure B.4 – PWB and cable of cell phone charger	35
Figure B.5 – Analysis of a single solder joint on a PWB	36
Figure B.6 – Spectra and results obtained on printed circuit board with two collimators	36
Figure B.7 – Examples of substance mapping on PWBs	38
Figure B.8 – SEM-EDX image of Pb free solder with small intrusions of Pb (size = 30 µm) ...	39
Table 1 – Tested concentration ranges for lead in materials	8
Table 2 – Tested concentration ranges for mercury in materials	9
Table 3 – Tested concentration ranges for cadmium in materials	9
Table 4 – Tested concentration ranges for total chromium in materials	9
Table 5 – Tested concentration ranges for total bromine in materials	9
Table 6 – Recommended X-ray lines for individual analytes	14
Table A.1 – Effect of matrix composition on limits of detection of some controlled elements	26

Table A.2 – Screening limits in mg/kg for regulated elements in various matrices	27
Table A.3 – Statistical data from IIS2	29
Table A.4 – Statistical data from IIS4	30
Table B.1 – Selection of samples for analysis of AC power cord	32
Table B.2 – Selection of samples (testing locations) for analysis after visual inspection – Cell phone charger.....	34
Table B.3 – Results of XRF analysis at spots (1) and (2) as shown in Figure B.6	37

INTRODUCTION

The widespread use of electrotechnical products has drawn increased attention to their impact on the environment. In many countries this has resulted in the adaptation of regulations affecting wastes, substances and energy use of electrotechnical products.

The use of certain substances (e.g. lead (Pb), cadmium (Cd) and polybrominated diphenyl ethers (PBDEs)) in electrotechnical products, is a source of concern in current and proposed regional legislation.

The purpose of the IEC 62321 series is therefore to provide test methods that will allow the electrotechnical industry to determine the levels of certain substances of concern in electrotechnical products on a consistent global basis.

WARNING – Persons using this International Standard should be familiar with normal laboratory practice. This standard does not purport to address all of the safety problems, if any, associated with its use. It is the responsibility of the user to establish appropriate safety and health practices and to ensure compliance with any national regulatory conditions.

DETERMINATION OF CERTAIN SUBSTANCES IN ELECTROTECHNICAL PRODUCTS –

Part 3-1: Screening – Lead, mercury, cadmium, total chromium and total bromine by X-ray fluorescence spectrometry

1 Scope

Part 3-1 of IEC 62321 describes the screening analysis of five substances, specifically lead (Pb), mercury (Hg), cadmium (Cd), total chromium (Cr) and total bromine (Br) in uniform materials found in electrotechnical products, using the analytical technique of X-ray fluorescence (XRF) spectrometry.

It is applicable to polymers, metals and ceramic materials. The test method may be applied to raw materials, individual materials taken from products and “homogenized” mixtures of more than one material. Screening of a sample is performed using any type of XRF spectrometer, provided it has the performance characteristics specified in this test method. Not all types of XRF spectrometers are suitable for all sizes and shapes of sample. Care should be taken to select the appropriate spectrometer design for the task concerned.

The performance of this test method has been tested for the following substances in various media and within the concentration ranges as specified in Tables 1 to 5.

Table 1 – Tested concentration ranges for lead in materials

Substance/ element	Lead									
Parameter	Unit of measure	Medium/material tested								
		ABS ^a	PE ^b	Low- alloy steel	Al, Al-Si alloy	Lead- free solder	Ground PWB ^c	Crystal glass	PVC ^d	Poly- olefine
Concentration or concentration range tested	mg/kg	15,7 to 954	14 to 108	30 ^e	190 to 930	174	22 000 to 23 000	240 000	390 to 665	380 to 640
^a Acrylonitrile butadiene styrene. ^b Polyethylene. ^c Printed wiring board. ^d Polyvinyl chloride. ^e This lead concentration was not detectable by instruments participating in tests.										

Table 2 – Tested concentration ranges for mercury in materials

Substance/element	Mercury		
Parameter	Unit of measure	Medium/material tested	
		ABS ^a	PE ^b
Concentration or concentration range tested	mg/kg	100 to 942	4 to 25
^a Acrylonitrile butadiene styrene.			
^b Polyethylene.			

Table 3 – Tested concentration ranges for cadmium in materials

Substance/element	Cadmium			
Parameter	Unit of measure	Medium/material tested		
		Lead-free solder	ABS ^a	PE ^b
Concentration or concentration range tested	mg/kg	3 ^c	10 to 183	19,6 to 141
^a Acrylonitrile butadiene styrene.				
^b Polyethylene.				
^c This cadmium concentration was not detectable by instruments participating in tests.				

Table 4 – Tested concentration ranges for total chromium in materials

Substance/element	Chromium					
Parameter	Unit of measure	Medium/material tested				
		ABS ^a	PE ^b	Low-alloy steel	Al, Al-Si alloy	Glass
Concentration or concentration range tested	mg/kg	16 to 944	16 to 115	240	130 to 1 100	94
^a Acrylonitrile butadiene styrene.						
^b Polyethylene.						

Table 5 – Tested concentration ranges for total bromine in materials

Substance/element	Bromine			
Parameter	Unit of measure	Medium/material tested		
		HIPS ^c , ABS ^a	PC/ABS ^d	PE ^b
Concentration or concentration range tested	mg/kg	25 to 118 400	800 to 2 400	96 to 808
^a Acrylonitrile butadiene styrene.				
^b Polyethylene.				
^c High impact polystyrene.				
^d Polycarbonate and ABS blend.				

These substances in similar media outside of the specified concentration ranges may be analysed according to this test method; however, the performance has not been established for this standard.

2 Normative references

The following documents, in whole or in part, are normatively referenced in this document and are indispensable for its application. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

IEC 62321-1, *Determination of certain substances in electrotechnical products – Part 1: Introduction and overview*¹

IEC 62321-2, *Determination of certain substances in electrotechnical products – Part 2: Disassembly, disjointment and mechanical sample preparation*¹

IEC/ISO Guide 98-1, *Uncertainty of measurement – Part 1: Introduction to the expression of uncertainty in measurement*

3 Terms, definitions and abbreviations

For the purposes of this document, the terms, definitions and abbreviations given in IEC 62321-1 and IEC 62321-2 apply.

4 Principle

4.1 Overview

The concept of 'screening' has been developed to reduce the amount of testing. Executed as a predecessor to any other test analysis, the main objective of screening is to quickly determine whether the screened part or section of a product:

- contains a certain substance at a concentration significantly higher than its value or values chosen as criterion, and therefore may be deemed unacceptable;
- contains a certain substance at a concentration significantly lower than its value or values chosen as criterion, and therefore may be deemed acceptable;
- contains a certain substance at a concentration so close to the value or values chosen as criterion that when all possible errors of measurement and safety factors are considered, no conclusive decision can be made about the acceptable absence or presence of a certain substance and, therefore, a follow-up action may be required, including further analysis using verification testing procedures.

This test method is designed specifically to screen for lead, mercury, cadmium, chromium and bromine (Pb, Hg, Cd, Cr, Br) in uniform materials, which occur in most electrotechnical products. Under typical circumstances, XRF spectrometry provides information on the total quantity of each element present in the sample, but does not identify compounds or valence states of the elements. Therefore, special attention shall be paid when screening for chromium and bromine, where the result will reflect only the total chromium and total bromine present. The presence of Cr(VI) or the brominated flame retardants PBB or PBDE shall be confirmed by a verification test procedure. When applying this method to electronics "as received", which, by the nature of their design, are not uniform, care shall be taken in interpreting the results. Similarly, the analysis of Cr in conversion coatings may be difficult due to the presence of Cr in substrate material and/or because of insufficient sensitivity for Cr in typically very thin (several hundred nm) conversion coating layers.

Screening analysis can be carried out by one of two means:

¹ To be published.

- non-destructively – by directly analysing the sample “as received”;
- destructively – by applying one or more sample preparation steps prior to analysis.

In the latter case, the user shall apply the procedure for sample preparation as described in IEC 62321-2. This test method will guide the user in choosing the proper approach to sample presentation.

4.2 Principle of test

The representative specimen of the object tested is placed in the measuring chamber or over the measuring aperture of the X-ray fluorescence spectrometer. Alternatively, a measuring window/aperture of a handheld, portable XRF analyser is placed flush against the surface of the object tested. The analyser illuminates the specimen for a preselected measurement time with a beam of X rays which in turn excite characteristic X rays of elements in the specimen. The intensities of these characteristic X rays are measured and converted to mass fractions or concentrations of the elements in the tested sample using a calibration implemented in the analyser.

The fundamentals of XRF spectrometry, as well as practical aspects of sampling for XRF, are covered in detail in [1, 2 and 3].

4.3 Explanatory comments

To achieve its purpose, this test method shall provide rapid, unambiguous identification of the elements of interest. The test method shall provide at least a level of accuracy that is sometimes described as semi-quantitative, i.e. the relative uncertainty of a result is typically 30 % or better at a defined level of confidence of 68 %. Some users may tolerate higher relative uncertainty, depending on their needs. This level of performance allows the user to sort materials for additional testing. The overall goal is to obtain information for risk management purposes.

This test method is designed to allow XRF spectrometers of all designs, complexity and capability to contribute screening analyses. However, the capabilities of different XRF spectrometers cover such a wide range that some will be relatively inadequate in their selectivity and sensitivity while others will be more than adequate. Some spectrometers will allow easy measurement of a wide range of sample shapes and sizes, while others, especially research-grade WDXRF units, will be very inflexible in terms of test portions.

Given the above level of required performance and the wide variety of XRF spectrometers capable of contributing useful measurements, the requirements for the specification of procedures are considerably lower than for a high-performance test method for quantitative determinations with low estimates of uncertainty.

This test method is based on the concept of a performance based measurement system. Apparatus, sample preparation and calibration are specified in this standard in relatively general terms. It is the responsibility of the user to document all procedures developed in the laboratory that uses the test method. The user shall establish a written procedure for all cases denoted in this method by the term “work instructions”.

The user of this test method shall document all relevant spectrometer and method performance parameters.

WARNING 1 Persons using the XRF test method shall be trained in the use of XRF spectrometers and the related sampling requirements.

WARNING 2 Xrays are hazardous to humans. Care shall be taken to operate the equipment in accordance with both the safety instructions provided by the manufacturer and the applicable local health and occupational safety regulations.

5 Apparatus, equipment and materials

5.1 XRF spectrometer

An XRF spectrometer consists of an X-ray excitation source, a means of reproducible sample presentation, an X-ray detector, a data processor and a control system [4, 5 and 6]:

- a) source of X-ray excitation – X-ray tube or radio-isotope sources are commonly used;
- b) X-ray detector (detection subsystem) – Device used to convert the energy of an X-ray photon to a corresponding electric pulse of amplitude proportional to the photon energy.

5.2 Materials and tools

All materials used in the preparation of samples for XRF measurements shall be shown to be free of contamination, specifically by the analytes of this test method. This means that all grinding materials, solvents, fluxes, etc. shall not contain detectable quantities of Pb, Hg, Cd, Cr and/or Br.

Tools used in the handling of samples shall be chosen to minimize contamination by the analytes of this test method as well as by any other elements. Any procedures used to clean the tools shall not introduce contaminants.

6 Reagents

Reagents, if any, shall be of recognized analytical grade and shall not contain detectable quantities of Pb, Hg, Cd, Cr and/or Br.

7 Sampling

7.1 General

It is the responsibility of the user of this test method to define the test sample using documented work instructions. The user may choose to define the test sample in a number of ways, either via a non-destructive approach in which the portion to be measured is defined by the viewing area of the spectrometer, or by a destructive approach in which the portion to be measured is removed from the larger body of material and either measured as is, or destroyed and prepared using a defined procedure.

7.2 Non-destructive approach

The user of this test method shall:

- a) establish the area viewed by the spectrometer and place the test sample within that area, taking care to ascertain that no fluorescent X-rays will be detected from materials other than the defined test portion. Usually, the area viewed by the spectrometer is a section of a plane delineated by the shape and boundary of the measuring window of the instrument. The area of the test sample viewed by the spectrometer shall be flat. Any deviation from the flat area requirement shall be documented;
- b) make sure that a repeatable measurement geometry with a repeatable distance between the spectrometer and the test portion is established;
- c) document the steps taken to disassemble a larger object to obtain a test portion.

7.3 Destructive approach

The following points shall be taken into account in the destructive approach: