

SIEVE ANALYSIS OF MOLECULAR SIEVE DESICCANTApplication

This test method describes the procedure used to determine the distribution of particle sizes in a sample of molecular sieve desiccant by shaking through a nest of U.S. standard sieves.

Apparatus RequiredSieve Shaking Machine

Ro-Tap machine or equivalent. VWR Scientific Catalog No. 57420-006.

Source: VWR Scientific
P.O. Box 855
Columbus, OH 43215

Sieves

The following U.S. standard 8 inch full height sieves shall be used unless otherwise specified. VWR Scientific catalog numbers are also provided for reference.

<u>U.S. Number</u>	<u>VWR Catalog No.</u>
3 1/2	57320-384
8	57320-486
20	57320-002
Pan	57355-006
Cover	57356-009

Analytical Balance

Accuracy to 1 mg.

Conditioning and Test Conditions

All test values indicated herein are based on material conditioned in a controlled atmosphere of 23 +/- 2 C and 50 +/- 5 % relative humidity for not less than 24 h prior to testing and tested under the same conditions unless otherwise specified.

Procedure

Note: The material is a desiccant. Sample must be taken from a previously unopened container.

1. Weigh 100 +/- 0.5 g of dry molecular sieve material. Record weight.
2. Stack sieves in order of mesh size with coarsest sieve on top and pan on bottom.



FORD LABORATORY TEST METHOD

BZ 005-01

3. Place weighed sample on top sieve (No. 3 1/2). Put cover in place.
4. Place nested sieves in Ro-Tap machine and shake for 10 +/- .3 minutes.
5. Remove the material collected on each sieve and weigh to the nearest 0.1 g.
6. Carefully remove the material collected on the pan and weigh to the nearest mg.
7. Divide weights of each fraction by the original weight and multiply by 100 to obtain percentage. Report each fraction to the nearest 0.1 % except for that collected in the pan which shall be reported to the nearest 0.01 %.

Chemicals, materials, parts, and equipment referenced in this document must be used and handled properly. Each party is responsible for determining proper use and handling in its facilities.

Materials & Fastener Quality
Research & Engineering Centre
Dunton

Engineering Materials & Standards
Environmental & Safety Engineering
Dearborn