

KES

Inoculants Die

KES G – B380B

(EST.) 1988 – 07 – 05

(REV.) 1990 – 03 – 02

(REV.) 1991 – 05 – 28

Contents

1. Scope of Application and Definition

2. Materials

3. Structure

4. Quality

5. Testing Method

6. Attention for Handling

Appendix – Drawing

1. Scope of application and definition

This shall be the storage box of inoculants used in inoculation on pouring zone, and applied to the storage box of inoculants.

2. Materials

- (1) 3.2t S45C
- (2) Angle 50 × 50 × 4t

3. Structure

Refer to appending drawing.

4. Quality

- (1) Electric welding on frame
- (2) No leakage on storage zone of inoculants

5. Testing method

- (1) Visual inspection of the shape
- (2) Check the state of sealing on storage zone.

6. Attention for handling

Be careful for breakage and distorting.