

KES

Liquid Silicicacid Soda

KES R – C611B

(EST.) 1979 – 01 – 13

(REV.) 1986 – 12 – 29

(REV.) 1991 – 06 – 18

Contents

1. Scope of Application
2. Inspection Items and Inspection Method
3. Inspection Lot
4. Method of Sample Picking
5. Test and Inspection
6. Making Decision
7. Management after Inspection
8. Miscellaneous

1. Scope of Application

This standard determines the import inspection for silicic acid soda, which is used for a subsidiary of device medicine of casting Cyl'Head of our company.

2. Inspection Items and Inspection Method

The inspection items and inspection method are as table 1.

Table 1

Inspection items	Inspection method	Remarks
Volume	Coefficient adjustment one time sampling inspection	Special inspection standard S – 2, AQL : 1.0
External appearance	“	“
Specific gravity	Checking method	Inspected by the supplier
Chemical contents	“	Submit the Inspection records

3. Inspection Lot

Consider the all products of one time delivery as 1 inspection lot.

4. Method of Sample Picking

(1) Volume, External Appearance

Follow the simple random sampling method of KS A 3151(Random sampling method) from a lot.

(2) Specific Gravity, Chemical Contents

After sampling 10% of containers of the sample by the simple random sampling method of KS A 3151 from a lot, divide them as the total sample amount to be 500mℓ and pick up the sample and mix it well.