

KES

Dross Seperation Medicine

KES R – C618B

(EST.) 1979 – 01 – 13

(REV.) 1986 – 12 – 31

(REV.) 1991 – 06 – 18

Contents

1. Scope of Application
2. Inspection Items and Inspection Method
3. Inspection Lot
4. Method of Sample Picking
5. Test and Inspection
6. Making Decision
7. Management after Inspection
8. Miscellaneous



1. Scope of Application

This standard determines the import inspection for Dross separation medicine, which is used in order to separate Dross of dissolved aluminum gushing bethtub.

2. Inspection Items and Inspection Method

The inspection items and inspection method are as table 1.

Table 1

Inspection items	Inspection method	Remarks
Weight	Coefficient adjustment type one time sampling method	Special inspection standard S-2, AQL : 1.0%
External appearance	Checking Inspection	N = 1lump
Mesh	"	Inspect at the supplier
Water contained	"	And submit the records
Specific gravity for looking	"	

3. Inspection Lot

Consider the all products of one time delivery as 1 inspection lot.

4. Method of Sample Picking

(1) Weight

Follow the simple random sampling method of KS A 3151(Random sampling method) from a lot.

(2) External Appearance, Mesh, Water Contained, specific gravity

Sample randomly 1 lump(kg) from a lot. Pick up 200g of sample after mixing it well. Here, it is the rule that you use the lump opened for only one day.