

KES

**Method for Analysis
of Magnesium in Zinc
Alloy Die Castings**

KES T – M200

(EST.) 1989 – 12 – 30

Contents

- 1. Scope of Application**
- 2. Summary**
- 3. Test Apparatus**
- 4. Reagent**
- 5. Test Method**
- 6. Handling Data**
- 7. Evaluation Standard**
- Additional Rule**



1. Scope of Application

This standard shall specify an atomic spectrophotometry method for specimen, which magnesium content in the zinc alloy die castings is 0.001 % ~ 0.1 %.

2. Summary

Dissolve the specimen with hydrochloric acid, measure the absorptivity of magnesium measuring line standard solution and the specimen at a range of wavelength 285.2 nm with the atomic spectrophotometer, and obtain concentration of the magnesium from the measuring line.

3. Test Apparatus

Atomic spectrophotometer

Remark : Follow KES T M 002 (Atomic Spectrophotometry Method) for manual.

4. Reagent

- (1) Hydrochloric acid (1 : 1)
- (2) Hydrochloric acid (1 : 9)
- (3) Hydrogen peroxide (30 %)
- (4) Magnesium standard solution (1.0 mgMg / mL) : Follow KS M 0002
(Production Method of Standard Solution Kinds for Chemical Analysis)
- (5) Pure zinc (Above 99.9 %)

5. Test Method

- (1) Measure exactly 10 g of the specimen and move to a beaker (300 mL).
(Amount of the specimen can be adjusted according to the magnesium content)
- (2) Cover a clock dish, put 50 mL of the hydrochloric acid (1 : 1), and add more little by little according to a reaction rate.