

Title: Calibration Of Kent Moore Four Probe Digital Thermometer

Scope

Work Instruction for the internal calibration of Kent-Moore Four Probe Digital Thermometers. To be used in the absence of a manufacturers calibration instruction.

Preparation

Calibration must be carried out using Category A Master instruments as required.

Equipment required;-

- 1.1 Haven OTB-7D Bath and Heater System.
- 1.2 Glass Thermometer.
- 1.3 Techne Fridge Unit.

Method

- 2.1 All calibration results must be entered on the results sheets (see appendix A).
- 2.2 Note the lab. temperature / R.H. and enter onto the results sheet.
- 2.3 Carry out tests 1 to 6 using items 1.1, 1.2 and 1.3.
- 2.4 Complete the results sheet header and enter Pass / Fail.

- All records must be kept for audit purposes

References

Appendix A Calibration Results for Kent-Moore Four Probe Digital Thermometer

Title: Calibration Of Kent Moore Four Probe Digital Thermometer

Appendix A

Calibration Results for Kent-Moore Four Probe Digital Thermometers

Model Serial No

Date Result

Lab Temp / RH Operator

User Location Certificate No

Accuracies quoted are from manufacturer's specifications or relevant British Standard.

Digital Thermometer

Accuracy : $\pm 2^{\circ}\text{F}$

Test No	Bath Temperature $^{\circ}\text{C}$	Digital Temperature $^{\circ}\text{F}$	Digital Thermometer Reading $^{\circ}\text{F}$	Allowed Limits	Results
1	- 20	- 4		- 6 to - 2	Pass / Fail
2	0	32		30 to 34	Pass / Fail
3	10	50		48 to 52	Pass / Fail
4	20	69		66 to 70	Pass / Fail
5	25	77		75 to 79	Pass / Fail
6	40	104		102 to 106	Pass / Fail

The UUT was calibrated using the following equipment:

1. Glass Thermometer S/N _____
2. Haven OTB-7D Bath and Heater System S/N _____
3. Techne Fridge Unit S/N _____

The uncertainty in the applied value is estimated not to exceed:

Temperature: $\pm 0.5^{\circ}\text{C}$

The uncertainty limits quoted refer to the applied values only and do not relate to the stability of the UUT.