

The information and data contained in this document were prepared by a technical working group of the Association. The working group and the Association assume no liability or responsibility in connection with the use of such information or data, including but not limited to any liability under patent, copyright, or trade secret laws. The user is responsible for determining that this document is the most recent edition published.

PLEASE NOTE: A TAPPI Useful Method (UM) is a document written to describe a test, procedure, or practice which may be proposed by a Working Group of no fewer than three TAPPI members not employed by the same organization and written in the same general style as a TAPPI Standard Test Method, but with the inclusion or exclusion of certain sections as deemed appropriate by the Working Group, and with minimum precision requirements that may be expanded at the discretion of the Working Group. A UM is written with no less attention to proper use of the language to describe the procedure using essentially the same elements of a TAPPI Standard Test Method, but in a less rigorous manner. TAPPI Useful Methods do not receive the same review through a rigorous process of openness, voluntary review, and consensus as do the TAPPI Standard Test Methods, and as such, are not intended to be used as referee methods as the TAPPI Standard Test Methods are.

CAUTION:

This method may include safety precautions which are believed to be appropriate at the time of publication of the method. The intent of these is to alert the user of the method to safety issues related to such use. The user is responsible for determining that the safety precautions are complete and are appropriate to their use of the method, and for ensuring that suitable safety practices have not changed since publication of the method. This method may require the use, disposal, or both, of chemicals which may present serious health hazards to humans. Procedures for the handling of such substances are set forth on Material Safety Data Sheets which must be developed by all manufacturers and importers of potentially hazardous chemicals and maintained by all distributors of potentially hazardous chemicals. Prior to the use of this method, the user must determine whether any of the chemicals to be used or disposed of are potentially hazardous and, if so, must follow strictly the procedures specified by both the manufacturer, as well as local, state, and federal authorities for safe use and disposal of these chemicals.

Freeness of pulp (Williams tester)

Scope

The Williams freeness tester provides a means of measuring freeness of stock from a beater or other refining equipment. The freeness is measured as the time (seconds) for drainage of 3 g of pulp in 1 L of water (0.3% consistency) through an 80-mesh wire screen.

Safety precautions

There are no particular additional safety precautions associated with this method.

Apparatus

1. *Williams freeness tester*, with a 1000-mL glass cylinder in a metal frame for holding the specimen, a screen for separating water from pulp, and a timer for measuring rate of drainage.
2. *Color-pad mold* or other sheet mold for extracting water for consistency determination (a Büchner funnel will serve the purpose).
3. *Hydraulic press* for pressing at 1379 kPa (200 psi).

Approved by a Working Group of TAPPI in accordance with the Useful Method Guidelines

Sampling and test specimens

For dried pulps, take a composite sample of at least 50 g dry and soak for 24 hours. Disintegrate the pulp using a standardized disintegrator (described in T 205 "Forming Handsheets for Physical Tests of Pulp," Appendix A) in 2 L of deionized or distilled water until fully dispersed. This can be checked visually by examining a very dilute sample portion of the pulp to see that no fiber bundles are present.

For slush pulps, take a representative sample equivalent to at least 10 g of dry fiber. Dilute, or concentrate, to 2 L total volume.

Using a Buchner funnel and filter flask determine the solids content (consistency) of the dispersed pulp. Apportion the remaining diluted pulp into two containers each containing 3.0 g equivalent weight of dry pulp.

Procedure

1. Stir the specimen in a small mixer with about 400-500 mL of water and adjust to a temperature of 25.5-26.5°C (78-80°F).
2. Prepare the tester to receive the diluted pulp specimen by pouring into the cylinder 500 mL of water at the same temperature. This is to prevent the pulp from striking the bare screen.
3. Pour the diluted pulp specimen into the tester cylinder, and adjust the level to 1000 mL.
4. With the timer set at zero, open the valve at the bottom of the tester.
5. Determine the freeness as the time required for the level to drop from 1000 mL to zero.
6. To determine consistency, combine the pulp from the chamber that was collected on the screen plate along with the discharge from the bottom drain port. Pour this combined slurry onto a tared filter paper in a Büchner funnel or in a low deckle sheet machine. Make sure no appreciable amount of fiber is left on the surface of the cylinder or on the screen plate. The filter paper and the pad is to be dried to constant weight in a weighing bottle at 105°C.
7. After oven drying and constant weight has been determined, the weight of the pad is calculated by subtracting the weight of the tared filter paper to obtain the weight of the pulp.

Calculation

Calculate the individual freeness value by the following:

$$\text{Freeness (s)} = (3.0 \times t) / W$$

where:

- t = drainage time, s
 W = moisture-free weight of specimen, g

Determine the average freeness value in seconds and report the value to one decimal place.

Report

Report the average of the two freeness values to one decimal place and reference the use of this Useful Method (UM 203). Note any deviations to the procedure.

Precision

Based on one sample of bleached northern softwood kraft dry lap pulp at three levels of refining, the averaged coefficient of variation is 9% as determined by the TAPPI spreadsheet (downloadable at <http://www.tappi.org/content/pdf/standards/useful.xls>) for the determination of Repeatability for Unlike Specimens.